



User Manual

PCE-GA 12 Leak Detector



User manuals in various languages (français, italiano, español, português, nederlands, türk, polski, русский, 中文) can be found by using our product search on: www.pce-instruments.com

Last change: 13 May 2020
v1.0



Contents

1	Safety notes	1
2	Features	2
3	Detectable gases	2
4	Technical specifications	3
5	Delivery contents	3
6	Device and display description	4
7	Operation	1
7.1	Before first use	1
7.2	Before use	1
7.3	Use	2
8	Further functions	3
8.1	Display backlight	3
8.2	Auto zero	3
8.3	Auto Power Off	3
8.4	Sensitivity	3
8.5	Alarms	3
9	Troubleshooting	3
10	Contact	4
11	Disposal	4

1 Safety notes

Please read this manual carefully and completely before you use the device for the first time. The device may only be used by qualified personnel and repaired by PCE Instruments personnel. Damage or injuries caused by non-observance of the manual are excluded from our liability and not covered by our warranty.

- The device must only be used as described in this instruction manual. If used otherwise, this can cause dangerous situations for the user and damage to the meter.
- The instrument may only be used if the environmental conditions (temperature, relative humidity, ...) are within the ranges stated in the technical specifications. Do not expose the device to extreme temperatures, direct sunlight, extreme humidity or moisture.
- Do not expose the device to shocks or strong vibrations.
- The case should only be opened by qualified PCE Instruments personnel.
- Never use the instrument when your hands are wet.
- You must not make any technical changes to the device.
- The appliance should only be cleaned with a damp cloth. Use only pH-neutral cleaner, no abrasives or solvents.
- The device must only be used with accessories from PCE Instruments or equivalent.
- Before each use, inspect the case for visible damage. If any damage is visible, do not use the device.
- Do not use the instrument in explosive atmospheres.
- The measurement range as stated in the specifications must not be exceeded under any circumstances.
- Non-observance of the safety notes can cause damage to the device and injuries to the user.
- The meter must not be used as a gas detector.

We do not assume liability for printing errors or any other mistakes in this manual.

We expressly point to our general guarantee terms which can be found in our general terms of business.

If you have any questions please contact PCE Instruments. The contact details can be found at the end of this manual.

2 Features

- Detection of flammable gases
- Vibration alarm when gases are detected
- Automatic calibration
- Measurement range up to 10000 ppm
- Audible alarm, 85 dB
- Sensor exchangeable
- Shelf life of the sensor approx. 5 years
- Rechargeable battery for mobile use

3 Detectable gases

- Ammonia
- Benzene
- Ethane
- Ethanol
- Ethylene
- Formaldehyde
- Hexane
- ISO-Butane
- Methane
- Propane
- P-Xylene
- Hydrogen sulfide
- Toluene
- Hydrogen
- and compounds in which these gases occur

4 Technical specifications

Measurement range	Low concentration: 0 ... 1000 ppm, High concentration: 0 ... 10000 ppm (methane only)
Audible alarm	Volume: 85 dB
Sensitivity	<10 ppm (methane)
Measuring interval	<2 seconds
Display	Flammable gas readings displayed on the LC display, bar graphs
Calibration	Automatic
Warm-up time	40 seconds
Battery	Polymer Li-Ion battery 18500 3.7 V 1400 mAh
Mains adaptor	Primary side: 100 ... 240 V, 50/60 Hz, 0.2 A
	Secondary side: 5 V, 1 A
Auto Power Off	Turns off automatically when battery is low or after 10 minutes of inactivity
Sensor shelf life	approx. 5 years (sensor is exchangeable)
Probe	Semi-rigid, approx. 500 mm
Weight	Approx. 430 g

5 Delivery contents


- 1 x gas leak detector PCE-GA 12
- 1 x charger
- 1 x user manual

6 Device and display description

- 1 - LC display
- 2 - Auto Zero
- 3 - Sensitivity high / low
- 4 - Auto Power Off
- 5 - Display backlight
- 6 - Audible alarm on / off
- 7 - Vibration alarm on / off
- 8 - Meter on / off



- 1 - Audible alarm
- 2 - Vibration alarm
- 3 - Automatic Power Off APO
- 4 - Calibration
- 5 - Bar graph
- 6 - Concentration display
- 7 - LEL display
- 8 - Automatic zero
- 9 - Battery level
- 10 - Factory settings
- 11 - Sensitivity high
- 12 - Sensitivity low
- 13 - LEL reading
- 14 - Maximum reading



7 Operation

7.1 Before first use

- Fully charge the battery before the first use. The charging socket is located on the right side above the sensor arm bracket.
- Switch on the meter using the "On / Off" key and leave the device switched on for about one hour for the sensor to acclimatise. Deactivate the automatic power-off function with the APO key.
- If you do not use the device for more than two months, repeat this procedure.

7.2 Before use

- Check the meter for mechanical damage.
- Only switch on the unit in an environment unpolluted by gas.
- Carry out a gas test with the appropriate test gas.
- **Attention! When using a lighter, only move the sensor head very slowly towards the gas source. A 100 % concentration exposure can destroy the sensor.**
- If the gas is not detected, the device is not ready for use.
- After the gas test, wait until the display shows "0".

7.3 Use

- Make sure the gas to be detected is listed above.
- Only turn on the meter in an environment unpolluted by gas.
Press and hold the "On / Off" key for about 1 second. The meter will vibrate and a signal tone will sound.
- Let the meter warm up for 40 seconds. The remaining time will be displayed.
- Select the desired sensitivity with the "H/L" key.
- Clean the areas to be examined from oil and dust. Oil and dust can impair the detection.
- Slowly move the sensor head to the area to be examined.
- If there is a gas leak, the instrument will signal that gas escapes (see chart below), depending on the sensitivity setting. Keep in mind the reaction time of at least 2 seconds. Move the sensor head back a little to exactly locate the leak.
- Switch off the meter after the leak detection. To do this, press and hold the "On / Off" key for about 1 second.

Alarm chart related to methane CH₄

Approx. reading in ppm		Audible alarm frequency x/s
Sensitivity		
high	low	
0	0	No alarm
0 ... 100	0 ... 1000	1
100 ... 400	1000 ... 4000	1.2
400 ... 700	4000 ... 7000	1.65
700 ... 1000	7000 ... 10000	3.25
>1000	>10000	6.25

8 Further functions

8.1 Display backlight

You can activate or deactivate the display backlight by pressing the "Display backlight" key (5).

8.2 Auto zero

The "Auto Zero" key is used to activate or deactivate automatic zeroing. Activating it improves sensitivity to the target gas and reduces the sensitivity to other existing gases which can influence the measurement.

8.3 Auto Power Off

The automatic power-off function switches off the unit after approx. 10 minutes of non-use to conserve the battery. With the "APO" key, this function can be deactivated.

8.4 Sensitivity

With the "H/L" key you can adjust the sensitivity according to your needs.

8.5 Alarms

Use the key with the vibration icon or with the speaker icon to switch the corresponding alarm on or off.

9 Troubleshooting

Error	Possible cause	Solution
Meter cannot be turned on	Battery flat	Charge battery
Display flashes Continuous signal tone	Sensor defective	Replace sensor ESS-PCE-GA 12
CAL is displayed	Calibration is due	Contact PCE Instruments for calibration



10 Contact

If you have any questions, suggestions or technical problems, please do not hesitate to contact us. You will find the relevant contact information at the end of this user manual.

11 Disposal

For the disposal of batteries in the EU, the 2006/66/EC directive of the European Parliament applies. Due to the contained pollutants, batteries must not be disposed of as household waste. They must be given to collection points designed for that purpose.

In order to comply with the EU directive 2012/19/EU we take our devices back. We either re-use them or give them to a recycling company which disposes of the devices in line with law.

For countries outside the EU, batteries and devices should be disposed of in accordance with your local waste regulations.

If you have any questions, please contact PCE Instruments.



PCE Instruments contact information

Germany

PCE Deutschland GmbH
Im Langel 4
D-59872 Meschede
Deutschland
Tel.: +49 (0) 2903 976 99 0
Fax: +49 (0) 2903 976 99 29
info@pce-instruments.com
www.pce-instruments.com/deutsch

Germany

PCE Produktions- und
Entwicklungsgesellschaft mbH
Im Langel 26
D-59872 Meschede
Deutschland
Tel.: +49 (0) 2903 976 99 471
Fax: +49 (0) 2903 976 99 9971
info@pce-instruments.com
www.pce-instruments.com/deutsch

The Netherlands

PCE Brookhuis B.V.
Institutenweg 15
7521 PH Enschede
Nederland
Telefoon: +31 (0)53 737 01 92
info@pcebenelux.nl
www.pce-instruments.com/dutch

United States of America

PCE Americas Inc.
711 Commerce Way suite 8
Jupiter / Palm Beach
33458 FL
USA
Tel: +1 (561) 320-9162
Fax: +1 (561) 320-9176
info@pce-americas.com
www.pce-instruments.com/us

France

PCE Instruments France EURL
23, rue de Strasbourg
67250 Soultz-Sous-Forêts
France
Téléphone: +33 (0) 972 3537 17
Numéro de fax: +33 (0) 972 3537 18
info@pce-france.fr
www.pce-instruments.com/french

United Kingdom

PCE Instruments UK Ltd
Unit 11 Southpoint Business Park
Ensign Way, Southampton
Hampshire
United Kingdom, SO31 4RF
Tel: +44 (0) 2380 98703 0
Fax: +44 (0) 2380 98703 9
info@pce-instruments.co.uk
www.pce-instruments.com/english

China

PCE (Beijing) Technology Co., Limited
1519 Room, 6 Building
Zhong Ang Times Plaza
No. 9 Mentougou Road, Tou Gou District
102300 Beijing, China
Tel: +86 (10) 8893 9660
info@pce-instruments.cn
www.pce-instruments.cn

Turkey

PCE Teknik Cihazları Ltd.Şti.
Halkalı Merkez Mah.
Pehlivan Sok. No.6/C
34303 Küçükçekmece - İstanbul
Türkiye
Tel: 0212 471 11 47
Faks: 0212 705 53 93
info@pce-cihazlari.com.tr
www.pce-instruments.com/turkish

Spain

PCE Ibérica S.L.
Calle Mayor, 53
02500 Tobarra (Albacete)
España
Tel. : +34 967 543 548
Fax: +34 967 543 542
info@pce-iberica.es
www.pce-instruments.com/espanol

Italy

PCE Italia s.r.l.
Via Pesciatina 878 / B-Interno 6
55010 Loc. Gragnano
Capannori (Lucca)
Italia
Telefono: +39 0583 975 114
Fax: +39 0583 974 824
info@pce-italia.it
www.pce-instruments.com/italiano

Hong Kong

PCE Instruments HK Ltd.
Unit J, 21/F., COS Centre
56 Tsun Yip Street
Kwun Tong
Kowloon, Hong Kong
Tel: +852-301-84912
jyi@pce-instruments.com
www.pce-instruments.cn