

User Manual

PCE-AC 2000 CO₂ Analyser



User manuals in various languages (français, italiano, español, português, nederlands, türk, polski, русский, 中文) can be found by using our product search on: www.pce-instruments.com

Last change: 29 December 2020
v1.0



Contents

1	Safety notes	1
2	Device description	2
2.1	Front side / CO ₂ traffic light.....	2
2.2	Rear side.....	2
3	Technical specifications	3
4	Operation	3
4.1	Power on CO ₂ analyser.....	3
4.2	Switch unit.....	3
4.3	Set alarm.....	3
5	Contact	4
6	Disposal	4

1 Safety notes

Please read this manual carefully and completely before you use the device for the first time. The device may only be used by qualified personnel and repaired by PCE Instruments personnel. Damage or injuries caused by non-observance of the manual are excluded from our liability and not covered by our warranty.

- The device must only be used as described in this instruction manual. If used otherwise, this can cause dangerous situations for the user and damage to the meter.
- The instrument may only be used if the environmental conditions (temperature, relative humidity, ...) are within the ranges stated in the technical specifications. Do not expose the device to extreme temperatures, direct sunlight, extreme humidity or moisture.
- Do not expose the device to shocks or strong vibrations.
- The case should only be opened by qualified PCE Instruments personnel.
- Never use the instrument when your hands are wet.
- You must not make any technical changes to the device.
- The appliance should only be cleaned with a damp cloth. Use only pH-neutral cleaner, no abrasives or solvents.
- The device must only be used with accessories from PCE Instruments or equivalent.
- Before each use, inspect the case for visible damage. If any damage is visible, do not use the device.
- Do not use the instrument in explosive atmospheres.
- The measurement range as stated in the specifications must not be exceeded under any circumstances.
- Non-observance of the safety notes can cause damage to the device and injuries to the user.

We do not assume liability for printing errors or any other mistakes in this manual.

We expressly point to our general guarantee terms which can be found in our general terms of business.

If you have any questions please contact PCE Instruments. The contact details can be found at the end of this manual.


2 Device description

2.1 Front side / CO₂ traffic light

CO₂ good / green:
0 ... 599 ppm


CO₂ OK / yellow:
600 ... 1199 ppm

CO₂ poor / red:
1200 ... 9999 ppm



2.2 Rear side

1. Mode key
2. Up key
3. Down key
4. Alarm key
5. °C / °F key
6. Socket for power supply



3 Technical specifications

CO₂	
Measurement range	0 ... 9999 ppm
Accuracy	±70 ppm ±5 % of rdg.
Resolution	1 ppm
Temperature	
Measurement range	-10 ... 100 °C
Resolution	0.1 °C
Accuracy	±1.5 °C
Relative humidity	
Measurement range	0 ... 99.9 % RH
Resolution	0.1 % RH
Accuracy	±3 %
General	
Traffic light function	green: 0 ... 599 ppm yellow: 600 ... 1199 ppm red: 1200 ... 9999 ppm
Alarm	adjustable, audible
Repeatability	<±0.5 %
Response time	10 s
Operating conditions	0 ... 50 °C, 0 ... 90 % RH, non-condensing
Storage conditions	-30 ... 70 °C, 0 ... 90 % RH, non-condensing
Power supply	via mains adaptor 9 VDC, 350 mA
Dimensions	388 x 288 x 43 mm
Weight	approx. 2420 g

4 Operation

4.1 Power on CO₂ analyser

As soon as you connect the mains adaptor to the CO₂ analyser via the plug socket, the analyser will power on. The initialisation time is 7 seconds. The meter displays a countdown. After the time has elapsed, the unit is ready for operation.

4.2 Switch unit

Press the °C/°F key to switch the unit for the temperature between °C and °F.

4.3 Set alarm

Press the mode key to set the alarm. Use the arrow keys to adjust the alarm value up or down. Once the desired value has been set, press the mode key to save the setting.

Note: An alarm value of 1200 ppm is set at the factory.



5 Contact

If you have any questions, suggestions or technical problems, please do not hesitate to contact us. You will find the relevant contact information at the end of this user manual.

6 Disposal

For the disposal of batteries in the EU, the 2006/66/EC directive of the European Parliament applies. Due to the contained pollutants, batteries must not be disposed of as household waste. They must be given to collection points designed for that purpose.

In order to comply with the EU directive 2012/19/EU we take our devices back. We either re-use them or give them to a recycling company which disposes of the devices in line with law.

For countries outside the EU, batteries and devices should be disposed of in accordance with your local waste regulations.

If you have any questions, please contact PCE Instruments.



PCE Instruments contact information

Germany

PCE Deutschland GmbH
Im Langel 4
D-59872 Meschede
Deutschland
Tel.: +49 (0) 2903 976 99 0
Fax: +49 (0) 2903 976 99 29
info@pce-instruments.com
www.pce-instruments.com/deutsch

United Kingdom

PCE Instruments UK Ltd
Unit 11 Southpoint Business Park
Ensign Way, Southampton
Hampshire
United Kingdom, SO31 4RF
Tel: +44 (0) 2380 98703 0
Fax: +44 (0) 2380 98703 9
info@pce-instruments.co.uk
www.pce-instruments.com/english

The Netherlands

PCE Brookhuis B.V.
Institutenweg 15
7521 PH Enschede
Nederland
Telefoon: +31 (0)53 737 01 92
info@pcebenelux.nl
www.pce-instruments.com/dutch

United States of America

PCE Americas Inc.
1201 Jupiter Park Drive, Suite 8
Jupiter / Palm Beach
33458 FL
USA
Tel: +1 (561) 320-9162
Fax: +1 (561) 320-9176
info@pce-americas.com
www.pce-instruments.com/us

France

PCE Instruments France EURL
23, rue de Strasbourg
67250 Soultz-Sous-Forets
France
Téléphone: +33 (0) 972 3537 17
Numéro de fax: +33 (0) 972 3537 18
info@pce-france.fr
www.pce-instruments.com/french

Italy

PCE Italia s.r.l.
Via Pesciatina 878 / B-Interno 6
55010 Loc. Gragnano
Capannori (Lucca)
Italia
Telefono: +39 0583 975 114
Fax: +39 0583 974 824
info@pce-italia.it
www.pce-instruments.com/italiano

China

PCE (Beijing) Technology Co., Limited
1519 Room, 6 Building
Zhong Ang Times Plaza
No. 9 Mentougou Road, Tou Gou District
102300 Beijing, China
Tel: +86 (10) 8893 9660
info@pce-instruments.cn
www.pce-instruments.cn

Spain

PCE Ibérica S.L.
Calle Mayor, 53
02500 Tobarra (Albacete)
España
Tel. : +34 967 543 548
Fax: +34 967 543 542
info@pce-iberica.es
www.pce-instruments.com/espanol

Turkey

PCE Teknik Cihazları Ltd.Şti.
Halkalı Merkez Mah.
Pehlivan Sok. No.6/C
34303 Küçükçekmece - İstanbul
Türkiye
Tel: 0212 471 11 47
Faks: 0212 705 53 93
info@pce- cihazlari.com.tr
www.pce-instruments.com/turkish

Hong Kong

PCE Instruments HK Ltd.
Unit J, 21/F., COS Centre
56 Tsun Yip Street
Kwun Tong
Kowloon, Hong Kong
Tel: +852-301-84912
jyi@pce-instruments.com
www.pce-instruments.cn