



PCE Americas Inc.
711 Commerce Way
Suite 8
Jupiter
FL-33458
USA
From outside US: +1
Tel: (561) 320-9162
Fax: (561) 320-9176
info@pce-americas.com

PCE Instruments UK Ltd.
Units 12/13
Southpoint Business Park
Ensign way
Hampshire / Southampton
United Kingdom, SO31 4RF
From outside UK: +44
Tel: (0) 2380 98703 0
Fax: (0) 2380 98703 9
info@pce-instruments.com

www.pce-instruments.com/english
www.pce-instruments.com

AC LEAKAGE Electrical Tester

PCE-LCT 1

USER'S MANUAL





TABLE OF CONTENTS

I .Features.....	1
II .Panel Description.....	2
III.Operation Instructions.....	4
A.AC Leakage current Measurements.....	4
1.Leakage current Flowing into Ground Conductor.....	4
2.Out of Balance Leakage current.....	5
3.Using the 50/60and Wide Selector.....	6
B.AC Load Current Measurement.....	7
C.AC Voltage Measurements.....	7
D.Resistance and continuity Measurement.....	8
E. Relative Reading Measurements.....	8
F. Holding the LCD Reading.....	8
G.Finding the MAX/MIN Value.....	8
H.Auto-Power-Off.....	9
IV.Specifications.....	9
V. Battery Replacement.....	10

I .Features

- 1.Accurate AC digital clamp meter for leakage current measurement.
- 2.10 μ A high resolution on 40mA range.
- 3.Shield transformer jaws to minimizs the effect of external stray magnetic field.
- 4.Large jaw with 30 mm diameter.
- 5.Five Ranges (40mA, 400mA,4A,40A,100A)for all application.
- 6.A filter circuit is designed to eliminate the effect of high frequency noise and harmonics by setting the frequency selector switch at the 50/60 Hz position for AC current measurement.
- 7.Large 3 3/4 digits LCD
- 8.Fast bargraph display (20 times/sec.)for transient observation.
- 9.Continuity and frequency measurements.
- 10.Max/Min and Data Hold functions.
- 11.Relative Measurement.
- 12.600V overload protection for ohm measurement.
- 13.Easy single rotary switch for any function selection.

II .Panel Description



1.Transformor Jaw

This is used to pick up current signal.To measure DC/AC current, conductor must be enclosed by the jaw.

2.Transformor Trigger

This is used to open the jaw.

3.Function Selector Switch

This is used to select the function user desired, such as ACV ,ACA,ohm and continuity.

4.Frequency Selection Switch

At 50/60Hz position,only the low frequency signal is measured.At wide position,signal from 40-1KHZ is measured.

5.Data Hold Button

once this button is pushed,reading shall be held on the LCD. Press again to release it.

6.Max/Min Hold Button

This button is used to enable the maximum or minimum value to be displayed and updated during measurement. Press once, minimum value shall be displayed and updated. press again, maximum value shall be displayed and updated. Press again (the third push),clamp meter return to normal measurement mode.

7.Zero/Relative Button

once this button is pressed, the current reading shall be set to zero and be used as a zero reference value for all other subsequent measurement.

8.LCD

This is a 3 3/4 digit liquid crystal display with maximum indication off 3999. Function symbols, units, bargraph, sign, decimal points, low battery symbols, Max/Min symbols, and zero symbol are included.

9.Low Battery Symbol

When this symbol appears, it means the battery voltage drops below the minimum required voltage. Refer to Section V for battery replacement.

10.Zero/Relative Symbol

When this symbol appears, it means a reference value has been subtracted from the actual reading. The reading shown is a offseted value. Press and hold the zero button for 2 seconds to disable this function.

11.Data Hold Symbol

Once the hold button is pressed, this symbol appears on LCD.

12.Bargraph

Bargraph has forty segments. It displays segments proportional to the actual reading. Each segment represent one count.

13. Max/Min Hold symbol

Once the Max/Min button is pressed, either MAX or MIN shall be displayed on LCD.

14.Continuity Symbol

If ohm and continuity function is selected, this symbol shall appears on LCD.

15.Units symbols

Once a function is selected, corresponding unit (V, Ω , A, or Hz) shall be displayed on LCD.

16.V Ω Hz input Terminal

This terminal is used as input for voltage, ohm/continuity, or frequency measurements.

17.COM Terminal


This terminal is used as common reference input.

18.Hand strap

Put your hand through the hole of hand strap to avoid accidental drop of the clamp meter.


III. Operation Instructions

A. AC Leakage Current Measurements





WARNING: Make sure that all the test leads are disconnected from the meter's terminals for current measurement.


1. Leakage current Flowing into Ground conductor



- a. Set the rotary switch at desired range.
- b. Press the trigger to open the jaw and fully encloses the wire goes to the ground. Make sure the two half jaws are properly closed.
- c. Read the measured value from the LCD display.

2. Out of Balance Leakage current





- a. Set the rotary switch at desired range
 - b. Press the trigger to open the jaw and fully enclose all two wires (single phase, two wires), three wires (three phases, three wires), or four wires (three phases, four wires). Make sure the two half jaws are properly closed.
 - c. Read the measured value from the LCD display.
3. Using the 50/60 and wide Selector

50/60 position


This clamp meter has very good frequency response due to the electric property of the transformer jaws used. Therefore, the measurement result contains not only the fundamental frequency of 50/60Hz but also the high frequencies and harmonics superimposed on the fundamental frequency. To eliminate the effect of high frequency noise, a low pass filter is designed to filter out high frequency signal. To enable the filter, set the switch at the 50/60 position. The filter's cut-off frequency is set at 100Hz with an attenuation characteristic of approx. 24dB/octave.

Wide position

If the circuit under test is originated from a high frequency generating device such as inverter, switching regulators, etc., then the switch should be set at wide position to measure the signal which contains the frequency from 40Hz-1kHz.


To make sure the presence of high frequency signal, set the switch at 50/60 and wide position to see the difference. If the reading is very different, it is certain that the high frequency signals or harmonics present.

B.AC Load Current Measurement



- a. Set the rotary switch at desired range.
- b. Press the trigger to open the jaw and fully enclose only one wire. No air gap is allowed between the two half jaws.
- c. Read the measured value from the LCD display.

C.AC Voltage Measurements



WARNING: Maximum input for DC V is 600, and for AC V is 600. Do not attempt to take any voltage measurement that exceeds the limits. Exceeding the limits could cause electrical shock and damage to the clamp meter.

- a. Set the rotary switch at 400V
- b. Insert the test leads into the input jack.
- c. Connect the test prods of the test leads in PARALLEL to the circuit to be measured.
- d. Read the measured value from the LCD display.

WARNING: Before taking any in-circuit resistance measurement, remove power from the circuit being tested and discharge all the capacitors.

D. Resistance and Continuity Measurement

1. Set the rotary switch at Ω
2. Insert the test leads into the input jack.
3. Connect the test prods of the test leads to the two ends of the resistor or circuit to be measured.
4. Read the measured value from the LCD display.
5. If the resistance is lower than $40\ \Omega$, a beeping sound shall be heard.

E. Relative Reading Measurements

The zero button also can be used to make a relative measurement. Once the button is pushed, the current reading is set to zero and a zero symbol shall be displayed on LCD. All the subsequent measurement shall be displayed as a relative value with respect to the value being zeroed. press the zero button for 2 seconds to return to normal mode.

F. Holding the LCD Reading

Press the HOLD button, then the reading shall be hold and kept on LCD.

G. Finding the MAX/MIN Value

Press the MAX/MIN button to enable the maximum and minimum values to be recorded and updated during measurement. Push the button once, the maximum value shall be displayed and updated. Push again (second push), the minimum value shall be displayed. Push again (third push), MAX/MIN function shall be disabled and return to the normal measurement mode.

H. Auto-Power-Off

The meter will turn itself off 30 minutes after power-on. To turn it on again, user can either press the HOLD button or turn the power off and turn it on again. To disable the Auto-power-off function, hold the HOLD button while turning on power.

IV.Specifications(23°C±5°C)

AC current:

Range	Resolution	Accuracy	
		50/60 Hz	Wide(400-1KHz)
40mA	10 μ A	$\pm 1.0\% \pm 0.5\text{mA}$	$\pm 4.5\% \pm 0.5\text{mA}$
400mA	100 μ A	$\pm 3.0\% \pm 5.0\text{mA}$	$\pm 3.0\% \pm 5.0\text{mA}$
4A	1mA	$\pm 4.0\% \pm 0.1\text{A}$	$\pm 4.0\% \pm 0.1\text{A}$
40A	10mA	$\pm 4.0\% \pm 1.0\text{A}$	$\pm 4.0\% \pm 1.0\text{A}$
80A	100mA	$\pm 2.5\% \pm 1.0\text{A}$	$\pm 3.0\% \pm 1.5\text{A}$
80-100A ¹	100mA	$\pm 5.0\% \pm 1.0\text{A}$	$\pm 5.0\% \pm 1.5\text{A}$

¹Though the meter can display up to 400A, it is not calibrated beyond 100A

AC Voltage(input impedance:10M Ω)

Range	Resolution			Overload protection
		50/60Hz	40-1KHz	
400V	0.1V	$\pm 1.5\% \pm 2\text{dgts}$	$\pm 2.0\% \pm 4\text{dgts}$	AC 600V

Resistance (Ω) and continuity: (open voltage 0.4V)

Range	Resolution	Accuracy	Beeping	OL Protection
40-400 Ω	0.1 Ω	$\pm 1.0\% \pm 2\text{dgts}$	<38.0 Ω	AC 600V

Conductor size: 30mm max.(approx.)

Battery Type: One 9V NEDA 1604

Display: 3 3/4 LCD with 40seg. bargraph

Range Selection: manual

Overload indication: left most digit blinks

Power Consumption: 10mA(approx.)

Low battery indication:  


Sampling Time: 2 times/sec.(display)

20 times/sec.(bargraph)

Operating Temperature: -10℃ to 50℃
Operating Humidity: less than 85% relative
Storage Temperature: -20℃ to 60℃

Storage Humidity: less than 75% relative
Dimension 210mm(L)×62.0mm(W)×35.6mm(H)
8.3" (L) ×2.4" (W) ×1.4" (H)
Weight: 200g(battery included)
Accessories: Carrying bag×1
Users manual×1
9V NEDA 1604×1

V. Battery Replacement



When the low battery symbol is displayed on the LCD, replace the old batteries with two new batteries.

- A. Turn the power off and remove the test leads from the clamp meter
- B. Remove the screw of the battery compartment.
- C. Slide off the battery compartment.
- D. Remove the old batteries.
- E. Insert one 9V NEDA 1604 or G6F22 batteries.
- F. Replace the battery compartment and secure the screw.