



Tursdale Technical Services Ltd
Unit N12B
Tursdale Business Park
Co. Durham
DH6 5PG
United Kingdom
Phone: +44 (0) 191 377 3398
Fax: +44 (0) 191 377 3357
info@tursdaletechnicalservices.co.uk
<http://www.industrial-needs.com/>

Manual Handhold Ultrasonic Flowmeter PCE-TDS-100



Table of contents

1. Introduction.....	4
1.1 Preface	4
1.2 Features	4
1.3 Principle of Measurement.....	5
1.4 Parts Identification	6
1.5 Typical Applications.....	8
1.6 Data Integrity and Built-in Time-Keeper	8
1.7 Product Identification.....	8
1.8 Specifications.....	9
2. Starting Measurement.....	9
2.1 Built-in Battery.....	9
2.2 Power On	10
2.3 Keypad.....	10
2.4 Menu Windows	11
2.5 Menu Windows Arrangement	11
2.6 Steps to Configure the Parameters	12
2.7 Transducers Mounting Allocation	12
2.8 Transducers Installation	13
2.8.1 Transducers Spacing.....	14
2.8.2 V-method Installation	14
2.8.3 Z-method Installation.....	14
2.8.4 W-method Installation.....	14
2.8.5 N-method Installation	15
2.9 Installation Checkup.....	15
2.9.1 Signal Strength	15
2.9.2 Signal Quality.....	15
2.9.3 Total Transit Time and Delta Time	15
2.9.4 Lime Ratio.....	15
3. How To	16
3.1 How to judge if the instrument works properly.....	16
3.2 How to judge the liquid flowing direction	16
3.3 How to change between units systems	16
3.4 How to select a required flow rate unit	16
3.5 How to use the totalizer multiplier	16
3.6 How to open or shut the totalizers.....	16
3.7 How to reset the totalizers.....	16
3.8 How to restore the flow meter with default setups.....	16
3.9 How to use the damper	16
3.10 How to use the zero-cutoff function.....	16
3.11 How to setup a zero point.....	17
3.12 How to get a scale factor for calibration	17

3.13 How to use the operation locker	17
3.14 How to use the built-in data logger.....	17
3.15 How to use the Frequency Output.....	17
3.16 How to use the Totalizer Pulse Output	17
3.17 How to produce an alarm signal.....	18
3.18 How to use the built-in Buzzer	18
3.19 How to use the OCT output.....	18
3.20 How to modify the built-in calendar	18
3.21 How to adjust the LCD contrast.....	18
3.22 How to use the RS232 serial interface	18
3.23 How to view the Date Totalizers	18
3.24 How to use the Working Timer	18
3.25 How to use the manual totalizer	19
3.26 How to check the ESN and other minor details	19
3.27 How to know how long the battery will last.....	19
3.28 How to charge the built-in battery	19
4. Menu Window Details	19
5. Troubleshooting.....	23
5.1 Power-on Error Displays and Counter-Measures	23
5.2 Error Code and Counter-Measures	24
5.3 Other Problems and Solutions	24
6. Communication Protocol	25
6. 0 General	25
6.1 Interface Pin-out Definition	25
6.2 The Protocol.....	25
6.3 Protocol Prefix Usage	26
6.4 Codes for the Keypad	27
7. Warranty and Service	27
7.1 Warranty	27
7.2 Service.....	27
7.3 Software Upgrade Service	27

1. Introduction

1.1 Preface

Welcome to the TDS-100 (Version 8.xx) series ultrasonic flow meter that has been manufactured with patent technologies and is equipped with more functions and advanced performance than our previous versions.

The Version 8.xx series ultrasonic flow meter has been upgraded based on the Version 7.xx series ultrasonic flow meter, which is still the main product line of the company. The new Version 8.xx retains most of the excellent features and functions of the previous versions: the pulse measurement technology, the ultrasonic igniting and the small signal receiving circuits etc. The main improvements are made on the battery supply circuit and on the transmitting circuits. "II other circuits are simply integrated into this new version without major modifications, due to the fact that we have already applied the most advanced measurement technologies and attained a more reliable model of ultrasonic flow meter.

The TDS-100 Series flow meter incorporates the latest ICs manufactured from the famous semiconductor manufacturers like Philips, Maxim, TI, Winbond, and Xilinx. The hardware features the ease of operation, high accuracy and outstanding reliability, while the software provides a very user friendly interface and much more functions. It employs a patent balanced lower voltage multi-pulse igniting circuit which increases the anti-interference ability magnificently so that the flow meter will work properly even in demanding industrial environments such as those with power frequency transverter working nearby.

Other outstanding features:

- the signal receiving circuits feature self-adapting performance so as to ensure that the user can easily operate the instrument without any adjustment.

- the built-in rechargeable +i-H battery can work continuously for more than 12 hours without recharge.

The advanced circuit design, the integration of the latest semiconductors, the user-friendly software interface both in English and Chinese languages and small-sized PCB board, all these features combine to make the TDS-100 series ultrasonic flow meter the best and the biggest seller on the Chinese market. Moreover, it is gaining more and more recognition on the international flow meter market

1.2 Features


- | | |
|---|--------------------------------|
| * 0.5% of linearity | * 0.2% of repeatability |
| * Bilingual interface in Chinese and English | * 4 flow totalizers |
| * Patent balanced lower-voltage multi-pulse ultrasonic igniting | * built-in date totalizers |
| * Work properly near transverters | * built-in data-logger |
| * 100 Pico-second resolution of time measurement | * 0.5 second totalizing period |

1.3 Principle of Measurement

The TDS-100 ultrasonic flow meter is designed to measure the fluid velocity of liquid within a closed conduit. The transducers are a non-contacting, clamp-on type, which will provide benefits of non-fouling operation and easy installation.

The TDS-100 transit time flow meter utilizes two transducers that function as both ultrasonic transmitters and receivers. The transducers are clamped on the outside of a closed pipe at a specific distance from each other. The transducers can be mounted in V-method where the sound transverses the pipe twice, or W-method where the sound transverses the pipe four times, or in Z-method where the transducers are mounted on opposite sides of the pipe and the sound crosses the pipe once. This selection of the mounting method depends on pipe and liquid characteristics. The flow meter operates by alternately transmitting and receiving a frequency modulated burst of sound energy between the two transducers and measuring the transit time that it takes for sound to travel between the two transducers. The difference in the transit time measured is directly and exactly related to the velocity of the liquid in the pipe, as shown in Figure 1.

$$v = \frac{MD}{\sin 2\theta} \times \frac{T}{T_{\text{up}} - T_{\text{down}}}$$



Where

θ is the include angle to the flow direction

M is the travel times of the ultrasonic beam

D is the pipe diameter

T_{up} is the time for the beam from upstream transducer to the downstream one


T_{down} is the time for the beam from downstream transducer to the upstream one

$T_{\text{up}} - T_{\text{down}}$


1.4 Parts Identification

Converter:


Top view



Front view




Bottom view




Transducers:


Standard-HM (50mm - 700mm)




Standard-HS (20mm - 100mm)
(Optional Accessories)




Cable 5m x2



Extended Cable 5m x2(Optional Accessories)



Converted Terminal and AC/DC Adapter:



1.5 Typical Applications

The TDS-100 flow meter can be virtually applied to a wide range of measurements. The measured pipe ranges 20-6000 mm [0.5 - 200 inch]. A variety of liquid applications can be accommodated: ultra-pure liquids, potable water, chemicals, raw sewage, reclaimed water, cooling water, river water, plant effluent, etc. Because the instrument and transducers are non-contacting and have no moving parts, the flow meter can not be affected by system pressure, fouling or wear. Standard transducers are rated to 110 $^{\circ}$ F. Higher temperatures can be accommodated. For further information, please consult the manufacturer for assistance.

1.6 Data Integrity and Built-in Time-Keeper

All user-inputted configuration values are retained in the built-in non-volatile flash memory that can store them for over 100 years, even if power is lost or turned off. Password protection is provided to avoid inadvertent configuration changes or totalized resets. A time-keeper is integrated in the flow meter for the index of date totalizing and works as the time base of flow accumulation. It keeps operating as long as the battery Cs terminal voltage is over 1.5V. In case of battery failure, the time-keeper will not keep running and it will lose proper time values. The user must re-enter proper time values in case the battery becomes totally exhausted. An improper time value affects no other functions but the date totalized.

1.7 Product Identification

Each set of the TDS-100 Series flow meter has a unique product identification or ESN written into the software that can only be modified with a special tool by the manufacturer. In case of any hardware failure, please provide this number which is located on menu window number M61 when contacting the manufacture.

1.8 Specifications

Linearity	0.5%
Repeatability	0.2%
Accuracy	1% of reading at rates > 0.2 mps
Response Time	0-999 seconds, user-configurable
Velocity	32 m/s
Pipe Size	20mm-6000mm
Rate Units	Meter, Feet, Cubic Meter, Liter, Cubic Feet, USA Gallon, Imperial Gallon, Oil Barrel, USA Liquid Barrel, Imperial Liquid Barrel, Million USA Gallons. User configurable.
Totalizer	7-digit totals for net, positive and negative flow respectively
Liquid Types	Virtually all liquids
Security	Setup values Modification Lockout. Access code needs unlocking
Display	4x8 Chinese characters or 4x16 English letters
Communication Interface	RS-232C, baud-rate: from 75 to 57600. Protocol made by the manufacturer and compatible with that of the FUJI ultrasonic flow meter. User protocols can be made on enquiry.
Transducers	Model M1 for standard, other 3 models for optional
Transducer Cord Length	Standard 2x10 meters, optional 2x 500 meters
Power Supply	3 AAA Ni-H built-in batteries. When fully recharged it will last over 10 hours of operation. 100V-240VAC for the charger
Data Logger	Built-in data logger can store over 2000 lines of data
Manual Totalizer	7-digit press-key-to-go totalizer for calibration
Housing Material	ABS
Case Size	100x66x20mm
Handset Weight	514g (1.2 lbs) with batteries

2. Starting Measurement

2.1 Built-in Battery

The instrument can operate either from the built-in Ni-H rechargeable battery, which will last over 10 hours of continuous operation when fully recharged, or from an external AC/power supply from the battery charger.

The battery charging circuits employ a scheme of constant-current and constant-voltage. It has a characteristic of fast charging at the beginning and very slow charging when the battery approaches to full recharge. Generally, when the green LED starts coming on, the battery would be nearly 95% recharged and when the red LED is off, the battery would be 98% recharged.

When fully recharged, the terminal voltage reaches around 4.25V. The terminal voltage is displayed on window M07. When the battery is nearly consumed, the battery voltage drops to below 3V. The user can obtain an approximate battery working time from the battery voltage.

A software battery working time estimator is integrated in this instrument based on the terminal voltage. Please note that the estimator may have relatively bigger errors in the estimated working time, especially when the voltage is in the range of around 3.70 to -3.90 volt.

2.2 Power On

Press the **[QN]** key to switch on the instrument and press the **[OFF]** to turn off the power.

Once the flow meter is switched on, it will run a self diagnostic program, checking first the hardware and then the software integrity. If there is any abnormality, corresponding error messages will display.

Generally, there should be no display of error messages, and the flow meter will go to the most commonly used Menu Window Number 01 (short for M01) to display the Velocity, Flow Rate, Positive Totalizer, Signal Strength and Signal Quality, based on the pipe parameters configured last time by the user or by the initial program.

The flow measurement program always operates in the background of the user interface. This means the flow measurement will keep on running regardless of any user menu window browsing or viewing. Only when the user enters new pipe parameters will the flow meter change measurement to the new parameter changes.

When new pipe parameters have been entered or when the power has been just switched on, the flow meter will enter an adjusting mode to make the signals magnified with proper amplification. By this step, the flow meter is going to find the best threshold of receiving signal. The user will see the progress by the number 1, 2, or 3, which are indicated on the right lower corner of the LCD display.

When the transducers have been adjusted on the pipe by the user, the flow meter will re-adjust the signal automatically.

Any user-entered configuration value will be retained into the NVRAM of the flow meter, until it is modified by the user.

2.3 Keypad

The keypad for the operation of the flow meter has 1602 keys, as shown by the right die

Key is 0 g 9 and are keys to enter numbers

Key is the **[▲/+]** going UP key, when the user wants to go to the upper menu window. It also works as 0 key when entering numbers

Key is **[◀]** the going DOWN key, when the user wants to go down-sided menu window. It also works as the '7' key when entering numbers.

Key is **[▼/-]** back space key, when the user wants go left or wants backspace the left character that is located to the left of the cursor.

Key is the **[ENT]** key for any inputting or selections.

Key **[MENU]** the key for the direct menu window jump over. Whenever the user wants to proceed to a certain menu window, the user can press this key followed by 2-digit numbers.

The **[MENU]** shortened as the 'M' key afterward when referring to the menu windows.

The **[QN]** key is for the power on.

The **[OFF]** key is for the power off.



2.4 Menu Windows

The user interface of this flow meter comprises about 100 different menu windows that are numbered by M00, M01, M02 ■ M99.

There are 2 methods to enter certain menu window:

(1) Direct going/entering. The user can press the **MENU** key followed by two-digit number keys. For example, the menu window M11 is for the entering of pipe outer diameter. The display will go to the M11 menu window after the user presses **MENU** **1** **1**.

(2) Pressing **▲/+** and **▼/-** keys. Each time of **▲/+** time key pressing will proceed to the lower-numbered menu window. For example, if the current window is on M12, the display will go to the number M11 window after pressing the **▲/+** key. There are three different types of menu windows:

- (1) Menu windows for number entering, like M11 for the entering of pipe outer diameter.
- (2) Menu windows for option selection/selecting options, like M14 for the selection of pipe materials.
- (3) Displaying windows only, like M00 to display Velocity, Flow Rate etc.

For number entering windows, the user can directly press the starting digit key when the user is going to modify the value. For example, when the current window is on M11 and the user is going to enter 219.2345 as the pipe outer diameter, the user can get the numbers entered by pressing the following serial keys:

2 **1** **9** **2** **3** **4** **5** **ENT**

or the option selection windows, the user should first press the **ENT** key to a selection modification and then select the relevant options by pressing the **▲/+** and **▼/-** keys or the digit keys to select the option with a number.

Antecedent to the option. In the end, the **ENT** key must be pressed to make the selection. For example, with menu window M14 for the selection of pipe material selection, (the **MENU** **1** **4** should be pressed first to enter this menu window if the current menu window is on a different window. The pipe material is stainless steel which has a number “1” antecedent to “stainless steel” on the display, the user should first press the **ENT** key to enter into a selection modification mode, then either make the selection by pressing the **▲/+** and **▼/-** keys to make the cursor on the line that displays “1. Stainless Steel”, or make the selection by pressing the 1 key directly.

Generally, the **ENT** key must be pressed to enter a modification mode. If the “Locked M47 Open’ message is indicated on the lowest line of the LCD display, it means the modification operations is locked out. In such cases, the user should go to M47 to have the instrument unlocked first before any further modification can be made.

2.5 Menu Windows Arrangement

M00GM09 windows for the display of the flow rate, velocity, date time, totalizers, battery voltage and estimated working hours for the battery.

M10GM29 windows for entering the pipe parameter.

M30GM38 windows for flow rate unit selections and totalizer unit selections.

M40GM49 windows for response time, zeroing, calibration and modification password setup.

M50GM53 windows for the built-in logger

M60-M78 windows for time-keeper initialization, version and ESN information viewing and alarms.

M82 window for viewing date totalizer.

M90GM94 are diagnostic windows for a more accurate measurement.

M97GM99 are not windows but commands for the outputting of display copying and pipe parameter setups. M00GM08 are windows for some additional functions, including a scientific calculator, viewer on records such as total working hours, turn-on and turn-off times, dates and times when the flow meter has been turned on or turned off.

Other menu windows such as M88 have no functions, or functions were cancelled because they are not applied to this version of the software.

The major reason why the menu windows are arranged in this way is that the software programmer hopes that the menu window arrangement for this version has the most/high LLLL compatibility with the previous versions of the flow meter software. This will make it easier for the former version users with this flow meter series.

2.6 Steps to Configure the Parameters

The following parameters need to be configured for a proper measurement:

- (1) Pipe outer diameter
- (2) Pipe wall thickness
- *Standard pipe materials and standard liquids refer to those with the sound parameters that have already been programmed into software of the flow meter, therefore there is no need to configure them
- (4) Liner material and its sound speed and thickness, if there is any liner.
- (5) Liquid type (for non-standard liquids, the sound speed of the liquid is also needed)
- (6) Transducer type adapted to the flow meter. Generally the Standard M1 or the Frame M-sized transducers will be the selected option.
- (7) Transducer mounting methods (the V-method or Z-method is the common option)
- (8) Check up the Space displayed on M25 and install the transducers accordingly.

For standard pipe materials and standard liquids, the following detailed step-by-step setup is recommended.

- (1) Press keys **MENU** **1** **1** to enter M11 window to input the digits for the pipe outer diameter, and then press **ENT** key.
- (2) Press key **▼/-** to enter M12 window to input the digits for the pipe outer diameter and then press **ENT** key.
- (3) Press key **▼/-** to enter M14 window, and press **ENT** key to enter the option selection mode.
Use keys **▲/+** and **▼/-** to scroll up down to the intended pipe material, and then press **ENT** key.
- (4) Press key **▼/-** to enter M16 window, press **ENT** key to enter the option selection mode, use keys **▲/+** and **▼/-** to scroll up and down to the liner material, and then press **ENT** key. Select "NO Liner", if there is no liner.
- (5) Press key **▼/-** to enter M20 window, press **ENT** enter the option selection mode, use keys **▼/-** and **▼/-** to scroll up and down to the proper liquid, and then press **ENT** key.
- (6) Press key **▼/-** to enter M23 window, press **ENT** key to enter the option selection mode, use keys **▲/+** and **▼/-** to scroll up and down to the proper transducer type, and then press **ENT** key.
- (7) Press key **▼/-** to enter M24 window, press **ENT** key to enter the option selection mode, use keys **▲/+** and **▼/-** to scroll up and down to the proper transducer mounting method, and then press **ENT** key.
- (8) Press key **▼/-** to enter M24 window to install the transducers on the pipe, and then press **ENT** key to go to M01 for the results.

The first-time users may need some time to get familiar with the operation. However, the user friendly interface of the instrument makes the operation quite easy and simple. Before long, the user will configure the instrument with very little key pressing, since the interface allows the user to go to the desired operation directly without any extra steps. The following tips will facilitate the operation of this instrument.








- (1) When the window display is between M00 to M09, press a number key x , the user will go directly to the M0x window. For example, if the current window displays M01, press 7 and the user will go to M07.
- (2) When the window display is under M00 to M09, press the ENT key and the user will go to M90; press ENT key to return. Press the dot key to go to M11 When the window display is under M25, press ENT key to go to M01

2.7 Transducers Mounting Allocation

The first step in the installation process is the selection of an optimum location in order to obtain a more accurate measurement. For this to be completed effectively, a basic knowledge about the piping and its plumbing system would be advisable.

An optimum location would be defined as a straight pipe length full of liquid that is to be measured.

The piping can be in vertical or horizontal position. The following table shows

Piping Configuration and Transducer Position	Upstream Dimension	Downstream Dimension
	L up x Diameters	L dn x Diameters
	10D	5D
	10D	5D
	10D	5D
	12D	5D
	20D	5D
	20D	5D
	30D	5D

examples of optimum locations.

Principles to selection of an optimum location

- (1) Install the transducers on a longer length of the straight pipe. The longer the better, and make sure that the pipe is completely full of liquid.
- (2) Make sure that the temperature on the location does not exceed the range for the transducers. Generally speaking, the closer to the room temperature, the better.
- (3) Take the pipe fouling into consideration. Select a straight length of a relatively newer pipe. If the condition is not satisfying, consider the fouling thickness as part of the liner for a better result.
- (4) Some pipes have a kind of plastic liner, and between the outer pipe and the liner there maybe a certain thickness difference that will prevent the ultrasonic waves from direct traveling. Such conditions will make the measurement very difficult. Whenever possible, try to avoid this kind of pipes. If impossible, try our plug-in transducers that are installed permanently on the pipe by drilling holes on the pipe while liquid is running inside.

2.8 Transducers Installation

The transducers used by the TDS-100 series ultrasonic flow meter are made of piezoelectric crystals both for transmitting and receiving ultrasonic signals through the wall of liquid piping system. The measurement is realized by measuring the travelling time difference of the ultrasonic signals. Since the difference is very small, the spacing and the alignment of the transducers are critical factors to the accuracy of the measurement and the performance of the system. Meticulous care should be taken for the installation of the transducers.

Steps to the installation of the transducers


- (1) Locate an optimum position where the straight pipe length is sufficient, and where pipes are in a favourable condition, e.g., newer pipes with no rust and ease of operation.
- (2) Clean any dust and rust. For a better result, polishing the pipe with a sander is strongly recommended.
- (3) Apply adequate coupler to the spot where the transducers are to be installed and leave no gap between the pipe surface and the transducers. Extra care should be taken to avoid any sand or dust particles left between the pipe outer surface and the transducers. To avoid gas bubbles inside the upper part of the pipe, the transducers should be installed horizontally by the side of the pipe.

2.8.1 Transducers Spacing

The spacing value shown on menu window M25 refers to the distance of inner spacing between the two transducers. The actual transducers spacing should be as close as possible to the spacing value.


2.8.2 V-method Installation

V-method installation is the most widely used mode for daily measurement with pipe inner diameters ranging from 20 millimeter to 300 millimeter. It is also called reflective mode or method.




2.8.3 Z-method Installation

Z-method is commonly used when the pipe diameter is between 300 millimeters and 500 millimeters.



2.8.4 W-method Installation

W-method is usually used on plastic pipes with a diameter from 10 millimeters to 100 millimeters



2.8.5 N-method Installation

Rarely used method.

2.9 Installation Checkup

Through the checkup of the installation, one can: check the receiving signal strength, the signal quality Q value, the traveling time difference of the signals, the estimated liquid speed, the measured traveling time of the signals and the calculated traveling time ratio. Therefore, optimum measurement result and longer running time of the instrument can be achieved.

2.9.1 Signal Strength

Signal strength indicates the amplitude of receiving ultrasonic signals by a 3-digit number. [000] means there is no signal detected, and [999] refers to the maximum signal strength that can be received.

Although the instrument works well if the signal strength ranges from 500 to 999, stronger signal strength should be pursued, because a stronger signal means a better result. The following methods are recommended to obtain stronger signals:

- (1) Relocate to a more favorable location, if the current location is not good enough for a stable and reliable flow reading, or if the signal strength is lower than 700.
- (2) Try to polish the outer surface of the pipe, and apply more coupler to increase the signal strength.
- (3) Adjust the transducers both vertically and horizontally while checking the varying signal strength, stop at the highest position, and then check the transducers spacing to make sure the transducers spacing is the same as what the M25 shows.

2.9.2 Signal Quality

Signal quality is indicated as the Q value in the instrument. A higher Q value would mean a higher Signal and Noise Ratio (short for SNR), and accordingly a higher degree of accuracy would be achieved. Under normal pipe condition, the Q value is in the range 600-900, the higher the better.

Causes for a lower Q value could be:

- (1) Interference of other instruments and devices such as a powerful transverse working nearby.
Try to relocate the flow meter to a new place where the interference can be reduced.
- (2) Bad sonic coupling for the transducers with the pipe. Try to apply more coupler or clean the surface, etc.
- (3) Pipes are difficult to be measured. Relocation is recommended.

2.9.3 Total Transit Time and Delta Time

The numbers displayed on menu window M93 are called total transit time and delta time respectively. They are the primitive data for the instrument to calculate the flow rate inside the pipe. So the flow rate indication will vary accordingly with the total time and delta time. The total transit time should remain stable or very little. If the delta time fluctuates higher than 20%, it means there are certain kinds of problems with the transducer installation.

2.9.4 Lime Ratio....

Between the Measured total transit time and the calculated time this ratio would be used to check the transducer installation. If the pipe parameters are entered correctly and the transducers are installed properly, the value for this ratio should be in the range of 1003. If this range is exceeded, the user should check:

- (1) If the pipe parameters are correctly entered.
- (2) If the actual spacing of the transducers is right and the same as what the window M25 shows.
- (3) If the transducers are installed properly in the right directions.
- (4) If the mounting location is good and if the pipe has changed shape or if there is too much fouling inside the pipes.
- (5) Other poor conditions.

3. How To

3.1 How to judge if the instrument works properly

When 'R' is displayed in the lowest right corner of LCD display, the instrument is working properly, generally speaking. If an 'H' flashes on that place, there could be poor signal received. Please refer to the chapters on diagnosis. If an 'I' is displayed, it means that there is no signal detected. If a 'J' is displayed, it means that the hardware of this instrument could be out of order. Refer to the chapter on diagnosis.

3.2 How to judge the liquid flowing direction

- (1) Make sure that the instrument works properly
- (2) Check the flow rate for the indication. If the displayed value is Positive, the direction of the flow will be from the RED transducers to the BLUE transducers; if the displayed value is Negative, the direction will be from the BLUE transducers to the RED transducers;

3.3 How to change between units systems

Use menu window M30 for the selection of unit system in English or Metric system.

3.4 How to select a required flow rate unit

Use menu window M31 to select the flow unit first and then the timing unit.

3.5 How to use the totalizer multiplier

Use window M33 to select a proper totalizer. Make sure that the totalizer pulse is appropriately speeded. It should not be too fast and neither too slow. A speed of producing a pulse in several seconds or minutes is preferable. If the totalizer multiplier is too small, there can be a loss of accumulation pulse because the output device can output only one pulse in a measurement period (500milliseconds) If the totalizer multiplier is too large, the output pulse will be too fewer for the devices that are connected with the instrument for a quicker response.


3.6 How to open or shut the totalizers

Use M34, M35 and M36 to turn on or turn off the POS, NEG, or NEI totalizer respectively.

3.7 How to reset the totalizers

Use M37 to reset the proper totalizer.

3.8 How to restore the flow meter with default setups

Use M37, when the 'selection' message is displayed. Press the dot key first and the message 'Master Erase' will display, then press the backspace key  the master erase step will erase all the parameters entered by the user and setup the instrument with default values.

3.9 How to use the damper

The damper acts as a filter for a stable reading. If '0' is entered in window M40, that means there is no damping. A bigger number brings a more stable effect. But bigger damper numbers will prevent the instrument from acting quickly. Numbers 0 to 10 are commonly used for the damper value.

3.10 How to use the zero-cutoff function

The number displayed in window M41 is called the low-cutoff value. The flow meter will replace these flow rate values that are absolutely less than the low-cutoff value with '0'. This means the flow meter will avoid any invalid accumulation when the actual flow is below the zero-cutoff value. The low-cutoff value

does not affect the flow measurement when the actual flow is absolutely greater than the low-cutoff value.

3.11 How to setup a zero point

There exists a 'Zero Point' with certain installation which means the flow meter will display a nonzero value when the flow is absolutely stopped. In this case, setting a zero point with the function in window M42 will bring a more accurate measurement result.

Make sure that the flow is absolutely stopped, then run the function in window M42 by pressing the ENI key.

3.12 How to get a scale factor for calibration

A scale factor is the ratio between the 'actual flow rate' and the indicated value by the flow meter. The scale factor can be determined by calibration with flow calibration equipment.

3.13 How to use the operation locker

The system locker provides a means of preventing inadvertent configuration changes or totalizer resets. When the system is locked, menu window browsing can be done without affecting any change, but any modifications are prohibited. The system can be locked without a password or with a one 1 to 4 digit password. With a no-password locking, directly press the ENI key when the password input prompt displays. If the password is forgotten, please contact the factory.

3.14 How to use the built-in data logger

The data logger has a space of 24K bytes of memory, which will hold about 2000 lines of data. Use M50 to turn on the logger and for the selection for the items that is going to be logged. Use M51 for the times when the logging begins and at how long an interval sustains and how long the data logging will last. Use M52 for the direction of logging data. The default setting will permit the logging data to be stored in the logger buffer. Logging data can be redirected to the RS-232C interface without being stored into the logger buffer. Use M53 to view the data in the logger buffer.

Dumping the logging data through the RS-232C interface and the clearing of the buffer can be operated with a function in window M52.

3.15 How to use the Frequency Output

There is a Frequency Output in all IDS-100 series flow meters. This frequency output signal, which represents the flow rate, is intended to connect with other instruments. The Frequency Output is totally user-configurable. Generally, four parameters should be configured for the setups. Enter the lower flow rate value in window M68 and the higher flow rate value in window M69. Enter the frequency range in window M67. For example, assume that the flow rate varies in a range 0m³/h to 3000m³/h, and an output signal is at a maximum frequency of 1000Hz, the minimum of 200Hz is going to be required for other instrumentation. The user should enter 0 in M68 and 3000 in M69, and enter 200 and 1000 in window M67. Please note that the user has to make the selection with OCI setups in window M78 by selecting the 13th option reading like 'FO output' to direct the frequency output to the OCI OUIPI hardware device.

3.16 How to use the Totalizer Pulse Output

The totalizer output will produce a pulse output with every unit flow of the totalizer.

Refer §3.4 and §3.5 for the setups of the totalizer units and multiplier. The totalizer pulse output can only be realized by mapping the pulse output to the OCI or BUZZER hardware devices.

For example, assume that the POS totalizer pulse output is needed, and every pulse should represent 0.1 cubic meter of liquid flow; the pulse output will be mapped to the internal Buzzer, so that with every 0.1 cubic meter of flow the BUZZER will beep for a while.

The following setups should be taken/performed:

- (1) Select the unit Cubic Meter under window M32.
- (2) Select the Multiplier as '2. X0.1' under window M33.
- (3) Select the output option '9. POS INT Pulse' under window M77. (INT stands for totalized)

3.17 How to produce an alarm signal

There are 2 types of hardware alarm signals that are available with this instrument. One is the Buzzer, and the other is the OCT output.

Both for the Buzzer and OCT output the triggering sources of the event include the following:

- (1) Alarms on when there is no receiving signal
- (2) Alarms on when there is poor signal received.
- (3) Alarms on when the flow meter is not in normal measurement modes. (4) Alarms on reverse flow.
- (5) Alarms on the overflow of the FrequencyOutput
- (6) Alarms on when the flow is out of a designated range set by the user.

There are two out-of-normal-range alarms in this instrument. They are called Q1 Alarm and Q2 Alarm.

The flow range can be user-configurable through M73, M74, M75, M76.

For example, assume that the Buzzer should start beeping when the flow rate is less than 300 m³/h and greater than 2000 m³/h, the following steps for setups would be recommended.

- (1) Enter 300 under M73 for Q1 alarm low flow rate
- (2) Enter 2000 under M74 for Q1 alarm high flow rate
- (3) Select the item reading like '6. Alarm Q1' under M77.

3.18 How to use the built-in Buzzer

The built-in buzzer is user-configurable. It can be used as an alarm. Use M77 for setups.

3.19 How to use the OCT output

The OCT output is user-configurable, which can be performed by selecting the proper input source such as pulse output. Use M78 for the setups. Please make sure that the FrequencyOutput shares the OCT.

The OCT output shares pins with the RS-232C interface, and the terminal is at Pin 6 and the ground is at Pin 6.

3.20 How to modify the built-in calendar

No modification on the built-in calendar will be needed in most cases. The calendar runs on insignificant amount of power supply. Modification will be required only in such cases as when the battery is totally consumed, or when the changing of the battery takes a long time. Press the ENT key under M61 for Modification. Use the dot key to skip over these digits that need no modification.

3.21 How to adjust the LCD contrast

Use M70 to the LCD contrast. The adjusted result will be stored in the EEPROM so that the MASTER ERASE will make no effect on the contrast.

3.22 How to use the RS232 serial interface

Use M62 for the setup of the RS-232C serial interface.

3.23 How to view the Date Totalizers

Use M82 to view the date totalizers that are comprised of a daily totalizer, a monthly totalizer and a yearly totalizer.

3.24 How to use the Working Timer

Use the working timer to check the time that has passed with a certain kind of operation. For example, use it as a timer to show how long a fully-charged battery will last. Under M72, press ENT key and then select YES to reset the timer.

3.25 How to use the manual totalizer

Use M28 for the manual totalizer. Press ENT key to start and stop the totalizer.

3.26 How to check the ESN and other minor details

Every set of the TDS-100 series flow meter utilizes a unique ESN to identify the meter. The ESN is an 8-digit number that provides the information of version and manufacturing date.

The user can also employ the ESN for instrumentation management.

The ESN is displayed in window M61. Other details about the instrument are the total working hours displayed in window MO1, and the total power-on times displayed in window MO4.

3.27 How to know how long the battery will last

Use M07 to check how long the battery will last. Also please refer to .2.1

3.28 How to charge the built-in battery

Refer to 2.1

4. Menu Window Details

Menu window No.	Function
M00	Display three positive negative net totalizers, signal strength, signal quality and working status
M01	DisplayPOS totalizer, flow rate, velocity, signal strength, signal qualityand working status
M02	DisplayNEG totalizer, flow rate, velocity, signal strength, signal qualityand working status
M03	DisplayNET totalizer, flow rate, velocity, signal strength, signal qualityand working status
M04	Displaydate and time, flow rate, signal strength, signal qualityand working status
M05	Displaydate and time, velocity, signal strength, signal qualityand working status
M06	Displaythe wave shape of the receiving signal
M07	Displaythe batteryterminal voltage and its estimated lasting time
M08	Displaythe all the detailed working status, signal strength, signal quality
M09	Displaytoday's total flow, velocity, signal strength, signal qualityand working status
M10	Window for entering the outer perimeter of the pipe
M11	Window for entering the outer diameter of the pipe 0 to 6000mm is the allowed range of the value.
M12	Window for entering pipe wall thickness
M13	Window for entering the inner diameter of the pipe
M14	Window for selecting pipe material Standard pipe materials (that the user need not know the speed) include: (0) carbon steel (1) stainless steel (2) cast iron (3) ductile iron (4) copper (5) PVC (6) aluminum (7) asbestos (8) fiberglass
M15	Window for entering the pipe material speed onlyfor non-standard pipe materials
M16	Window for selecting the liner material, select none for pipes without anyliner Standard liner materials that the user need not know the speed include: (1) Tar Epoxy (2) Rubber (3) Mortar (4) Polypropylene (5) Polystyrol (6)Polystyrene (7) Polyester (8) Polyethylene (9) Ebonite (10) Teflon
M17	Window for entering the liner material speed onlyfor non-standard liner materials
M18	Window for entering the liner thickness, if there is a liner
M19	Window for entering the ABS thickness of the inside wall of the pipe
M20	Window for selecting fluid type For standard liquids that the user need not know the liquid speed include: (0) Water (1) Sea Water (2) Kerosene (3) Gasoline (4) Fuel oil (5) Crude Oil (6) Propane at -45C (7) Butane at 0C (8)Other liquids (9) Diesel Oil (10)Caster Oil (11)Peanut Oil (12) Q90 Gasoline (13) Q93 Gasoline (14) Alcohol (15) Hot water at 125C

M21	Window for entering the fluid sonic velocity only for non-standard liquids
M22	Window for entering the viscosity of the non-standard liquids
M23	Window for selecting the proper transducers There are 14 different types of transducers for selection. If the user-type-transducers are used, 4 user type wedge parameters, which will be prompted by the software, should be entered following. If the n type transducers are used, 3 n type transducers and pipe parameters should be entered following.
M24	Window for selecting the transducer mounting methods Four methods can be selected: (0) V-method (1) Z-method (2) N-method (3) W-method
M25	Display the transducer mounting spacing
M26	Entry to store the parameter configuration into the internal NVRAM
M27	Entry to load one set of saved parameters
M28	Select YES or NO for the instrument to determine whether or not to hold (or to keep) the last correct value when poor signal condition occurs. YES is the default setup
M29	Enter a value ranging from 000 to 999. 0 is the default value
M30	Window for selecting unit system. Default value is 'Metric'. The change from English to Metric or vice versa will not affect the unit for totalizers.
M31	Window for selecting flow rate that will be used by the instrument afterward. Flow rate can be in 0. Cubic meter short for (m3) 1. Liter (l) 2. USA gallon (gal) 3. Imperial Gallon (igl) 4. Million USA gallon (mgl) 5. Cubic feet (cf) 6. USA liquid barrel (bal) 7. Imperial liquid barrel (ib) 8. Oil barrel (ob) The flow unit in terms of time can be per day, per hour, per minute or per second. So there are 36 different flow rate units in total for selection.
M32	Window for selecting the totalizers' working unit
M33	Select totalizer multiplier
M34	Turn on or turn off the NET totalizer
M35	Turn on or turn off the POS totalizer
M36	Turn on or turn off the NEG totalizer
M37	(1) Totalizer reset (2) Restore the instrument to the default parameters as the manufacturer did

	by pressing the dot key followed by the backspace key. Take care or make note on the parameters before doing the restoration
M38	Press-a-key-to-run or to stop totalizer for easier calibration
M39	Operational interface language selection in Chinese and English. This selection makes it possible that more than 2 billions of people on the world can read the menu.
M40	Flow rate damper for a stable value. The input range is 0 to 999 seconds. 0 means there is no damping. Default value is 10 seconds
M41	Lower flow rate cut-off to avoid invalid accumulation.
M42	Zero point setup under the condition when there is no liquid running inside the pipe.
M43	Clear the zero point set by the user, and restore the zero point set by the manufacturer
M44	Set up a manual flow bias. Generally this value should be 0.
M45	Scale factor for the instrument. The default value is '1'. Keep this value as '1', when no user calibration has been made.
M46	Network environment Identification Number. Any integer can be entered except 13(ODH, carriage return), 10 (0AH, line feeding), 42 (2AH), 38, 65535. Every set of the instrument in a network environment should have a unique IDN. Please refer to the chapter for communication.
M47	System locker to avoid modification of the parameters
M48	Not used
M49	Communication tester
M50	"Option" selection for the built-in logger. It also functions as the switch of logger
M51	Time setup for the data logger
M52	(1) Data logging direction control. If 'To RS-232' is selected, all the data produced by the data logger will be transmitted out through the RS-232 interface (2) If 'To buffer' is selected, the data will be stored into the built-in logger memory (3) Buffer transferring and buffer clearing
M53	Logger buffer viewer. It functions as a file editor. Use Dot, backspace UP and DN keys to browse the buffer. If the logger is ON, the viewer will automatically refresh once new data are stored
M54	Not used
M55	Not used
M56	Not used
M57	Not used
M58	Not used
M59	Not used
M60	99-year calendar. Press ENT for modification. Use the dot key to skip the digits that need no adjusting.

M61	Display Version information and Electronic Serial Number (ESN) that are unique for each TDS-100 series flow meter. The users can employ the ESN for instrumentation management
M62	RS-232 setup. Baud rate can be 75 to 115200 bps
M63	Not used
M64	Not used
M65	Not used
M66	Not used
M67	Input the frequency range for the frequency output. The biggest range is 0Hz-9999Hz. Default value is 1-100 Hz
M68	Enter a flow rate value that corresponds to lower frequency
M69	Enter a flow Rate value that corresponds to higher frequency
M70	LCD display backlight control. The entered value indicates how many seconds the backlight will be on with every key pressing.
M71	LCD contrast control. The LCD will become darker when a small value is entered.
M72	Working timer. It can be cleared by pressing ENT key, and then select YES.
M73	Enter Lower Flow Rate value that will trigger the Q1 Alarm. There are two virtual alarms in the system. By "virtual" we mean that the user must redirect the output of the alarms by setting up the output hardware in M78 and M77
M74	Enter the higher flow rate value that will trigger the Q1 Alarm.
M75	Enter the lower flow rate value that will trigger the Q2 Alarm.
M76	Enter the higher flow rate value that will trigger the Q2 Alarm.
M77	Buzzer setup. If a proper input source is selected, the buzzer will beep when the trigger event occurs
M78	OCT (Open Collect Transistor Output) setup By selecting a proper input source, the OCT hardware will close when the trigger event occurs
M79	Not used
M80	Work as a keypad and display for another handheld set by RS-232 connected with the handset
M81	Not used
M82	Date totalizer
M83	Not used
M84	Not used
M85	Not used
M86	Not used

M87	Not used
M88	Not used
M89	Not used
M90	Displays signal strength, signal quality, time ratio on the upper right corner.
M91	Displays the Time Ratio between the Measured Total Transit Time and the Calculated time. If the pipe parameters are entered correctly and the transducers are properly installed, the ratio value should be in the range of 100 ±3%. Otherwise the entered parameters and the transducer installation should be checked.
M92	Displays the estimated fluid sound velocity. If this value has an obvious difference with the actual fluid sound speed, pipe parameters entered and the transducer installation should be checked again.
M93	Displays total transit time and delta time(transit time difference)
M94	Displays the Reynolds number and the pipe factor used by the flow rate program.
M95	Not used
M96	Not used
M97	Command to record the pipe parameters entered by the user either to the built-in data logger or to RS-232C serial interface
M98	Command to record the diagnostic information either to the built-in data logger or to RS-232C serial interface
M99	Command to copy the current display either to the built-in data logger or to RS-232C serial interface
M00	Browse the 64 recorded instrument power-on and power-off date and time with the flow rate at the time of power on and off
M01	Displays the total working time of the instrument
M02	Displays the last power-off date and time
M03	Displays the last power-off flow rate
M04	Displays the times of instrument powered on(the instrument has been powered on)
M05	A scientific calculator for the convenience of field working. All the values are in single accuracy. The drawback is that the user can't operate it by direct key-pressing
M06	Not used
M07	Not used
M08	Not used
M09	Not used
M-0	Entry to hardware adjusting windows only for the manufacturer

5. Troubleshooting

5.1 Power-on Error Displays and Counter-Measures

The TDS-100 series ultrasonic flow meter provides an automatic power-on diagnosis for the hardware problems. When any message (with the power on) in the following table displays, counter-measures should be taken.

Error message	causes	Counter-measures
RtM Testing Error Segment Test Error	Problem with the software	(1)Power on again (2)Contact with factory
Stored Data Error	The parameters entered by the user lose integration.	When this message displays, the user should press ENT key, and all the configuration will be restored to the default state.
Timer Slow Error Timer Fast Error	Problem with the timer-keeper or the crystal oscillator.	(1)Power on again (2)Contact with factory
Date Time Error	Number errors with the calendar	Initialize the calendar by menu window M61
Reboot repetitivel	Hardware problems	Contact the factory

5.2 Error Code and Counter-Measures

The TDS-100 series ultrasonic flow meter will show Error Code in the lower right corner with a single letter like 1, R etc. on menu windows M00, M01, M02, M03, M90 and M08. When any abnormal Error Code shows, counter-measures should be taken.

Error code	Correspondent Message displayed on M08	Causes	Counter-measures
R	System Normal	No error	
I	Detect No Signal	(1)No Signals detected (2)Transducers installed improperly (3)Too much fouling (4)Pipe liners are too thick. (5)Transducer cords are not properly connected	(1)Relocate measuring location (2)Clean the spot (3)Check the cords
J	Hardware Error	Hardware problem	Contact the factory
!	PoorSig Detected	(1)Poor signal detected (2)Transducers installed improperly (3)Too much fouling (4)The pipe liners are too thick.	(1)Relocate measuring place (2)Clean the spot (3)Check the cords (4)Check the coupler
&	Frequ OutputOver	The actual frequency for the Frequency Output is out of the range set by the user	Check the value entered at M66, M67, M68 and M69, and try to enter a larger value on M69
"	System RAM Error Date Time Error CPU or TRQ Error ROM ParityError	(1) Temporary problems with RAM, RTC (2) Permanent problems with hardware	(1) power on again (2) contact factory
# \$ %	Adjusting Gain	Instrument is in the progress of adjusting the gain for the signal, and the number indicates the progressive steps	
K	Empty pipe	(1) No liquid inside pipe (2) Setup error on M29	(1) Relocate where the pipe is full of liquid (2) Enter 0 on M29

5.3 Other Problems and Solutions

- (1) When the actual flow inside the pipe is not standstill, but the instrument displays 0.0000 for the flow rate, and 'R' displaying signal strength and the signal quality Q (value) has a satisfactory value? The problems are likely a used by the user who has used the 'Set Zero' function on this non- standstill flowing pipe. To solve this problem, use the 'Reset Zero' function on menu window M43.
- (2) The displayed flow rate is much lower or much higher than the actual flow rate in the pipe under normal working conditions.
 - (a) There is probably an offset value wrongly entered by the user in M44. Enter '0' in M44.
 - (b) Problem with transducer installation.
 - (c) There is a 'Zero Point'. Try to 'zero' the instrument by using M42 and make sure that the flow inside the pipe should be standstill.
- (3) The battery can not work as long as the time period as indicated by M07
 - (a) Battery should be replaced due to the end of the service life.
 - (b) Newly changed battery does not fit the battery estimating software. Customizing the battery with the software should be taken. Please contact the factory.
 - (c) The battery has not been fully recharged or the recharge has been stopped too many times halfway.

- (d) There is indeed a time difference between the actual working time and the estimated one, especially when the terminal voltage is in the range 3.70 and 3.90 volt. Please refer to battery voltage for a closer estimated working time.

6. Communication Protocol

6.0 General

The TDS-100 series ultrasonic flow meter integrates a standard RS-232C communication interface and a complete set of communication protocols that are compatible with that of the Fuji's ultrasonic flow meter.

6.1 Interface Pin-out Definition

P	1	for batteryrecharge, positive input
	2	RXD
	3	TXD
	4	not used
	5	GND
	6	OCT output
	7	not used
	8	for battervrecharge, negative input
	9	RING input for connecting a MODEM

6.2 The Protocol

The protocol is comprised of a set of basic commands that is a string in ASCII format, ending with a carriage (CR) and line feed (LF). Commonly used commands are listed in the following table.

Command	Function	Data Format
DQD(CR)	Return flow rate per day	d.dddddddE dd(CR)NLF> *
DQH(CR)	Return flow rate per hour	d.dddddddE dd(CR)NLF>
DQM(CR)	Return flow rate per minute	d.dddddddE dd(CR)NLF>
DQS(CR)	Return flow rate per second	d.dddddddE dd(CR)NLF>
DV(CR)	Return flow velocity	d.dddddddE dd(CR)NLF>
DIO(CR)	Return POS totalizer	dddddddE d(CR)NLF> **
DI-(CR)	Return NEG totalizer	dddddddE d(CR)NLF>
DIN(CR)	Return NET totalizer	dddddddE d(CR)NLF>
DID(CR)	Return Identification Number	dddddd (CR) (LF)
DL(CR)	Return signal strength and quality	S6ddd,ddd Q6dd (CR) (LF)
DT(CR)	Return date and time	yy-mm-dd hh:mm:ss(CR) (LF)
M@(CR)***	Send a keyvalue as if a keyis pressed	
LCD(CR)	Return the current window display	

FOdddd(CR)	Force the FO output with a frequency in dddd Hz	
ESN(CR)	Return the ESN for the instrument	Dddddddd(CR)(LF)
RING(CR)	Handshaking Request by a MODEM	
OK(CR)	Response from a MODEM	No action
GA	Command for GSM messaging	Please contact factory for detail
GB	Command for GSM messaging	
GC	Command for GSM messaging	
DUMP(CR)	Return the buffer content	In ASCII string format
DUMP0(CR)	Clear the whole buffer	In ASCII string format
DUMP1(CR)	Return the whole buffer content	In ASCII string Format, 24KB in length
W	Prefix before an Identification Number in a network environment. The IDN is a word, ranging 0-65534.	
N	Prefix before an Identification Number in a network environment. The IDN is a single byte value, ranging 00-255.	
P	Prefix before any command	
&	Command connector to make a longer command by combining up to 6 commands	

Notes CR stands for Carriage Return and LF for Line Feed. 'd' stands for the 0G9 digit numbers.

*** @ stands for the key value, e.g., 30H for the '0' key.

6.3 Protocol Prefix Usage

(1) Prefix P

The prefix P can be added before any command in the above table to have the returning data followed with two bytes of CRC check sum, which is the adding sum of the original character string.

Take the DIO(CR) command as an example. Assume that DIO (CR) would return O1234567EO0m3 (CR)(LF) (the string in hexadecimal is 2BH, 31H, 32H, 33H, 34H, 35H, 36H, 37H, 45H, 2BH, 30H, 6DH, 33H, 20H, 0DH, 0AH), then PDI(CR) would return O1234567EO0m3!F7(CR)(LF).

'!' acts as the starter of check sum which is yielded by adding up the string 2BH, 31H, 32H, 33H, 34H, 35H, 36H, 37H, 45H, 2BH, 30H, 6DH, 33H, 20H.

Please note that there will be SPACES (20H) before '!'.

(2) Prefix W

The prefix W should be used in the network environment. The usage format is W O digit string which stands for the IDN O basic command.

The digit string should have a value between 0 and 65534 except 13(0DH), 10 (OAH), 42(2AH,*), 38(26H, &).

For example, if the IDN612345 instrument is addressed and returning the velocity of that instrument is requested, the command will be W12345DV(CR).

(3) Prefix N

The prefix N is a single byte IDN network prefix, not recommended in a new design. It is reserved only for the purpose of the compatibility with the former versions

(4) Command Connector &

The & command connector can connect up to 6 basic commands to form a longer command so that it will make the programming much easier.

For example, assume that the measurement of an instrument with IDN64321 are going to be returned, and (then) all the following 3 values--- (1) flow rate (2) velocity (3) POS totalizer---will be returned simultaneously. The combined command would be W4321DQD&DV&DIO(CR), and the result would be: O1.234567EO12m3/d(CR) O3.1235926EOOOm/s(CR) O1234567EOO0m3(CR)

6.4 Codes for the Keypad

The codes for the keypad should be used when the instrument is connected with other terminals that operate the instrument by transmitting the 'M' command along with the keypad code. By this function, remote operation of this instrument can be realized, even via the Internet.

Key	Hexadecimal Keycode	Decimal Keycode	ASCII Code
8	38H	56	8
9	39H	57	9
	3AH	58	:
	3BH,0BH	59	;
MENU	3CH,0CH	60	<
NET	3DH,0DH	61	6
/1	3EH	62	>
	3FH	63	?

Key	Hexadecimal Keycode	Decimal Keycode	ASCII Code
8	38H	56	8
9	39H	57	9
	3AH	58	:
	3BH,0BH	59	;
MENU	3CH,0CH	60	<
NET	3DH,0DH	61	6
/1	3EH	62	>
	3FH	63	?

7. Warranty and Service

7.1 Warranty

The manufacturer provides one year warranty on all products, free of charge, but the users should be responsible for the one-way transportation fee from the customer to the factory.

7.2 Service

The manufacturer provides instrument installation for our customers, and the charges will be made according the cost. For any hardware failure of the instrument, we recommend that our customers send back the instrument to our factory for service, due to the fact that the instrument is made of microprocessors and it will be difficult to perform field maintenance. Before sending back the instrument, please try to contact the factory first to make sure what the problem is.

For other operational problems, please contact our service department by telephone, fax or email and internet. In most cases, the problem could be solved immediately.

7.3 Software Upgrade Service

We provide free-of-charge software upgrade services. Please contact the factory for any lately developed software.

In this direction will find a vision of the measurement technique:
<http://www.industrial-needs.com/measuring-instruments.htm>

NOTE: "This instrument doesn't have ATEX protection, so it should not be used in potentially explosive atmospheres (powder, flammable gases)."