


# PidifiX Guide

V1.0



## CONFIGURATION SOFTWARE

Please download the software "PidifiX" from website or consult your supplier to get any help. Run \*.exe file to install the software and then the software shortcut "PidifiX" will be shown on OS's desktop. Run the PidifiX as below.

### Channels

- High and Low Limit. To set high and low limit and violation events will happen when exceeding the set limit.
- Alarm Delay. when limit violation events happen, alarm will happen after the set alarm delay time.
- Accumulation. if unselected, it will be single-type, and alarm will happen after set alarm delay. And if limit violation events removed before this delay, alarm won't happen. If selected, alarm will happen when the total time of the violation events exceeds the set alarm delay.

-Temperature unit: °C/°F To choose between centigrade and Fahrenheit temperature.

-Ext. If data logger needs to use an external probe, select it.

### Sample Interval Time

To choose sample interval. The elapsed days will be calculated based on the sample interval and maximum memory capacity.

### Start Delay

This decide start time actually. Once pressing button to start, data logger will start after the start delay time.

### LCD ON

for those data loggers with LCD, user can select it to enable LCD display.

### Stop by Button

If selected, data logger can be stopped by button.

**Note: user uses it to avoid that logger be stopped by wrong operations.**

### Restart

If selected, data logger can be restarted without software configuration.

**Note: once restart the logger, it will delete all recorded data. Before operate this, user has to confirm the data have been saved.**

### File Type

The data logger supports to generate pdf, dlg(raw file), csv, xls or txt directly, and user can select the file type that will be generated.

### Save as

User can click the button to use the software(Pidifi) to get csv, xls, txt and dlg(raw file) file.

### Refresh

Click this button to refresh shown information and status for current logger.

### Calibration

Click this button to enter into calibration mode. for more details, please contact dealers.

### Password

User can set password for current logger. Once password set, user must input right password to access.

### Report

User can set PDF report title, trip no. and description.

### Time and Zone

User can set time zone according to user's country.

### Read Back

Click this button to read the latest configuration from logger.

### Configure

After finish all settings, Click this button to setup

## Important:

**To get professional software, help, or a software that supported FDA 21 part 11 and cloud server, please visit our website or contact local distributors.**