



PCE Americas Inc.  
711 Commerce Way  
Suite 8  
Jupiter  
FL-33458  
USA  
From outside US: +1  
Tel: (561) 320-9162  
Fax: (561) 320-9176  
info@pce-americas.com

PCE Instruments UK Ltd.  
Units 12/13  
Southpoint Business Park  
Ensign way  
Hampshire / Southampton  
United Kingdom, SO31 4RF  
From outside UK: +44  
Tel: (0) 2380 98703 0  
Fax: (0) 2380 98703 9  
info@pce-instruments.com

[www.pce-instruments.com/english](http://www.pce-instruments.com/english)  
[www.pce-instruments.com](http://www.pce-instruments.com)

## Technical Adhesion Tester PCE-TAT 10

### Tensile Adhesion Tester PCE-TAT 10

**Simple design and easy operation, allows Adhesion Tester PCE-TAT 10 to be used for daily adhesion testing /  
Using glue with fast curing base allows the user to perform tests in shorter time frame**

The simple design and an absolutely straightforward operation make it possible for the practitioner to use the adhesion tester as an instrument for daily adhesion tests. Using adhesive with rapid curing, the tests can be performed by the user in the shortest possible time.

The pull-off type adhesion tester is designed to measure the adhesion value of paints and other coatings on the base and between layers or cohesive materials. The tensile adhesion tester PCE-TAT 10 is manufactured according to EN13144 and ISO 4624.

The testing with the mechanical tensile adhesion tester PCE-TAT 10 is performed in the following way. On the testing cover a dolly is glued and, after the glue is dried, it is pulled-off with the spring-system of the device. The force which is applied for pulling-off the glued dolly is displayed as a numerical value on the scale of the device. This value is the value of adhesion.

### Specifications

Breakout force	200 kg
Diameter of base dolly, mm	15.1 (№ 1) and 19.5 (№ 2)
Specific breakout force, MPa	Dolly №1 up to 10 MPa (100) Dolly №2 up to 6 MPa (60)
Scale, MPa	1 (№ 1) and 2 (№ 2)
Weight of adhesion tester, kg, no more	1
Dimensions of adhesion tester, mm	150×70
Dimensions of package, mm	L180*W150*H100

### Delivery

- 1 x Adhesion tester PCE-TAT 10
- 1 x Dollies: № 1 – 3 pcs., № 2 – 3 pcs.
- 1 x Ballerina (cutter) for cutting the area of testing
- 1 x Two-component epoxy adhesive
- 1 x CA glue
- 1 x Operating manual
- 1 x Case