



PCE Americas Inc.
711 Commerce Way
Suite 8
Jupiter
FL-33458
USA
From outside US: +1
Tel: (561) 320-9162
Fax: (561) 320-9176
info@pce-americas.com

PCE Instruments UK Ltd.
Units 12/13
Southpoint Business Park
Ensign way
Hampshire / Southampton
United Kingdom, SO31 4RF
From outside UK: +44
Tel: (0) 2380 98703 0
Fax: (0) 2380 98703 9
info@pce-instruments.com

www.pce-instruments.com/english
www.pce-instruments.com

Technical Conductivity Meter PCE-SM 11

Salt Meter to determine salt content in liquids

With the Salt Meter PCE-SM 11 conductivity in non-saturated solutions can be quickly and accurately determined. The Salt Meter PCE-SM 11 has a high measuring accuracy thanks to the automatic temperature compensation. The Salt Meter PCE-SM 11 is smaller, faster and more accurate at measuring salt content than a refractometer. The Salt Meter can be used for water conditioning, quality control, galvanizing techniques, etc. Measuring values are digitally displayed as a percentage (max. 12% of the weight).

- Measurement range up to 12 % of the weight
- Automatic temperature compensation
- Min. / max / HOLD
- Auto shut-off to protect battery life.
- Compact and maneuverable .
- Water resistant (IP 67)

Technical Specifications

Measurement range	0,0 ... 12,0 % (weight percentage)
Accuracy	± 0,5 %
Resolution	0,01 %
Temperature compensation	automatic from 0 ... to +50 °C
Power	4 x 1,5 V AAA batteries (included)
Operating conditions	0 ... +60 °C / <80 % H.r .
Dimensions	190 x 40 mm
Weight	171g

Delivery contents:

- 1 x Salt Meter PCE-SM 11
- 4 x batteries
- 1 x user's manual