

Your FMD measurement
data available fast,
simple and accurately
on PC or laptop for
reporting, statistics or
calculations

New !

FMD REPORT 6 SOFTWARE



brookhuis

APPLIED DATA INTELLIGENCE

FMD Report 6

De latest software for the Brookhuis FMD moisture meters, which enables you to import the measurement data of your FMD moisture meter on your laptop or PC. Statistics with and without filters, subdivide into batches, analyze measurement data or batches, standard deviation, average value. Export measurement data to and edit in Excel. Sorting using adjustable limits for minimum and maximum values.

info@brookhuis.com +31534803636



Results

INFO

Creator: Marielle
Date: 2000-00-00 00:01:59
Temperature: 20.0°C
Species: SPRUCE,NORWAY
Package: Woodpacket
Instrument: FMD6,nr:01021174
Supplier: Enschede
Batch: MGO
Thickness:
Width:

RESULTS

Average Value: 15.10%
Minimum Value: 7.60%
Maximum Value: 21.20%
Number: 15
Reliability: 11.30% - 18.80%
Deviation: 2.60%
Values: [17.00], [21.20], [20.00], [17.80], [15.10], [12.40], [12.60], [8.90], [7.60]

Delete record Close

*FMDDefault.fmd - FMD Report 6 Software

File Edit Extra Help

ENABLE FILTERS

MEASUREMENTS

Date	Moisture	Temperature	Number	Species	Package	Batch
*2000-00-00 00:01	15.10%	20.0°C	15	SPRUCE,NORWAY	Woodpacket	MGO

MOISTURE CONTENT STATISTICS

Number	Accepted	Dry	Wet	Average	Minimum	Maximum	Rel1	Rel2
1	1 (100.0%)	0 (0.0%)	0 (0.0%)	15.10%	15.10%	15.10%	15.10%	15.10%

STATUS

Limits have been set! (Min Limit=10.00 Max Limit=18.00)
Importing data from FMD6...
Total of 1 records have been imported...
Import done!

Export

EXPORT SETTINGS

Export statistics
 Export measurements
Delimiter: Semicolon (;)
 Use custom

Export... Cancel

ENABLE FILTERS

Date:	Moisture	Temperature	Number	Species:	Package:
2000-01-01 00:00	Min: 10	Min:	Min:	SPRUCE,NORV	Woodpacket
2080-01-01 00:00	Max: 18	Max:	Max:		

MEASUREMENTS

Date	Moisture	Temperature	Number	Species	Package	Batch
*2000-00-00 00:01	15.10%	20.0°C	15	SPRUCE,NORWAY	Woodpacket	MGO