



Benchtop Scale PCE-PB 60N



Benchtop scale PCE-PB 60N up to 60 kg, Bidirectional USB interface, PEAK hold function, Counting function, Mains and battery operation including USB interface cable

The USB platform scale of the PCE-PB N series is a versatile platform scale. The functions of the USB platform scale are very extensive, but one function is particularly interesting for shipping. It is the bidirectional USB interface of the platform scales that enables control by the PC. However, the USB platform scales of the PCE-PB N series can be used with the optional, inexpensive "ProCell" software. This software simulates keyboard input, similar to a scanner. With the help of this software, the platform scale can then transfer the weight value into active fields.

Another advantage of this platform scale is the wired display. The display is supplied with a stand, but it is also suitable for wall mounting. Other interesting functions of the platform scales are the piece counting function, PEAK hold function, function for level control, measuring units such as kg / lb / N (Newton) / g, adjustable background lighting, adjustable automatic switch-off and the option to operate the scales with power pack or batteries.

- ▶ Bidirectional USB interface
- ▶ Spiral cable can be extended to approx. 1.5 m / 59"
- ▶ Digit height 20 mm / 0.78"
- ▶ Stainless steel platform
- ▶ PEAK function (maximum value display)
- ▶ Piece counting function with reference number of pieces
- ▶ Multiple tare
- ▶ Function for level control (drum weighing)
- ▶ Mains or battery operation
- ▶ USB interface cable incl.

Subject to change

Specifications

Weighing range (Max)	60 kg / 132 lbs
Minimum load (Min)	60g / 2.1 oz
Readability (d)	20g / 1.7 oz
Possible measuring tolerance	± 80 g / 2.8 oz
Weighing plate (L x W x H)	300x 300 x 45 mm / 11 x 11 x 1.7"
Display	LCD20 mm / 0.78" digit height (illuminated) 90cm/ 35" spiral cable extendable to approx. 1.5 m / 60" (Plug connection on the display)
Display cable	
Measurement units	kg/ g / lb / N (Newton) -PEAK Hold Function (maximum value display) - multiple tare over the full measuring range - level control (auto tare OFF function)
Functions	- piece counting function (min.1 pc) - animal weighing function - adjustable filters for fast response time - adjustable shutdown and lighting
Interface	USB bidirectional (query with Sx + CR + LF)
Working temperature	+5 ... +35 °C / 41 ... 95 °F / max. 85% r.H.
Power supply	DC9V / 200 mA power supply unit or 6 x AA 1.5V batteries
Dead weight	ca.4 kg / 8.8 lbs
Recommended calibration weight	M1 class (freely selectable)

More information

Manual



More product info



Similar products



Subject to change