



Color Matching Cabinet PCE-CIC 11



**Color lighting chamber for color matching / For use in quality control/ Hour counter / Large viewing area / Easy to clean interior
/ Simulation of six light types**

The color matching box PCE-CIC 11 is a simulation tool, which is mainly used in quality control. The color matching cabinet accurately corrects light types and thus allows direct comparison of products that must have special color characteristics. The color matching box PCE-CIC 11 supports six possible lighting types. These colors are supplied as standard: "A/F", "D65", "TL84/F11", "UV", "CWF" and "TL83/U30".

Metamerism can be prevented by the use of a color matching box. An hour counter is installed in the color matching box, which, in addition to the hours, also allows the general use of the respective illuminant. This makes it easier to stick to the recommended running time of the lamps. The type of light required can be selected on the switchboard of the color matching box. In addition to the single unit, it is also possible to switch to mixed light by simultaneously pressing the required buttons on the switching bar.

- ▶ Simulation of different light types
- ▶ Hour counter for each light type
- ▶ Short warm-up time
- ▶ According to ASTM D1729, ISO3664, DIN, ANSI, BSI
- ▶ Easy to clean housing
- ▶ Optimal illumination of the cabin

Subject to change

Specifications

House light	A / F
Artificial daylight	D65
Fluorescent light	TL84 / F11
Ultraviolet	UV
Office / business / storage roomlight CWF	
Business / office lighting in the USA	TL83 / U30
Measurements	695 x 552 x 502 mm ASTM D1729, ISO3664
Standards	DIN ANSI BSI

More information

Manual



More product info



Similar products



Subject to change