



# Paper Scale Round Sample Cutter PCE-FSC 50



**Paper scale round sample cutter for 50 cm<sup>2</sup> samples, robust and compact, four blades, up to 5 mm**

The paper scale round sample cutter impresses with its compact dimensions and the robust steel housing. With the four internal blades of the round sample cutter, you can cut out a 50 cm<sup>2</sup> sample (fleece, paper, leather, textile, cork, ...) within seconds, a quarter turn is sufficient, and you can measure its weight per unit area.

- ▶ Robust and compact
- ▶ Four internal stainless steel blades
- ▶ Up to 0-5 mm / 0-0.19" material thickness
- ▶ 50 cm<sup>2</sup> / 7.75 in<sup>2</sup> sample size
- ▶ With mechanical lock
- ▶ Suitable for many materials

Subject to change

## Specifications

Sample thickness	max. 0-5 mm / 0-0.19"
Sample cut-out	<b>50 cm<sup>2</sup> / 7.75 in<sup>2</sup></b>
Housing	cast steel
Cutting blades	stainless steel
Dimensions	124 mm / 4.88", Ø 124 mm / 4.88"
Weight	ca. 500 g / 17.6 oz

## More information

**More product info**



**Similar products**



Subject to change