

Benchtop Scale PCE-SCS 150



Low-cost benchtop scale up to 150 kg, Readability 10 g, Mains and battery operation, Large 20 mm LC display, Removable stainless steel platform, Zero and tare function

The benchtop scale has a 400 x 500 mm stainless steel platform that can be removed for cleaning. Flexible use of the mobile platform scale is made possible not only by the light weight and compact dimensions, but also by the independent power supply, which is possible with the 6V4Ah rechargeable battery.

If the 4 load cells of the benchtop scale with a weighing capacity of 150 kg and a resolution of only 10 g require an adjustment, this can be done quickly and easily using external weights (optional) in the calibration function of the platform scale. Thanks to the key operation, the fast response time of the platform scale and the easy-to-read 20 mm LCD display, this platform scale is ideally suited for mobile and fast weighing applications.

- ▶ Platform size 400 x 500 mm / 15.7 x 19.7"
- ▶ Shockproof plastic housing
- ▶ 20 mm LCD display
- ▶ Battery operation
- ▶ Automatic energy saving mode
- ▶ Tare function
- ▶ Weighing units kg and lb.
- ▶ Flat and light construction

Specifications

Weighing range	150 kg / 330 lb
Readability	10 g / 0.35 oz
Taring range	over the full range
Settling time	adjustable
Weighing units	kg / lb
Display	20 mm / 0.78" LCD backlit
Platform size	400 x 500 mm / 15.7 x 19.7" (stainless steel)
Calibration	by external adjustment weight (optional)
Operating temperature	-10 °C ... 40 °C / 14 °F ... 104 °F
Interface	RS232
Memory	18 values
Power supply	100-240V 50 / 60Hz - 12V adapter Rechargeable battery: 6V4Ah
Battery life	130 hours
Input signal	analog 10.6 mV / V - 3 mV / V
Linearity	≤ 0.01% F.S.
Dimensions	680 x 660 x 150 mm / 26.7 x 26.0 x 5.9"
Weight	8 kg / 17.6 lb

More information

More product info



Similar products



Subject to change