

Inspection Camera with Telescoping Pole PCE-IVE 300



PCE-IVE 300 Inspection Camera
For quick analysis of parts and structures / 1 m (3.3 ft)telescopic pole / Movable gooseneck head

PCE-IVE 300 is a borescope inspection camera that comes with a rigid telescoping pole that extends up to 1 m / 3.3 ft in length. Ideal for inspecting gutters, chimneys and structures as well for inspecting parts and under vehicles, the borescope camera captures both picture and video and saves the files to an SD card memory (included).

The waterproof and dust proof IP68-rated cable makes the borescope perfectly suited for everyday work in harsh conditions at construction sites and more.

- ▶ Telescopic pole extends up to 1 m / 3.3 ft
- ▶ Gooseneck camera head diameter of 28 mm / 1.11 in
- ▶ Waterproof and dust proof IP68 ingress protection rating = No ingress of dust; complete protection against contact (dust tight) and waterproof; meaning the cable can be underwater for 30 minutes at depths of up to 1.5 m / 4.9 ft

Specifications

Cable length 1 m / 3.3 ft

Cable type Rigid telescopic pole

Camera head diameter Ø 28 mm / 1.11 in

Depth of field $10 \text{ mm} / 0.4 \text{ in ...} \infty$

Field of view / viewing angle 150.8°
Ingress protection rating IP68

Illumination Automatic
White balance Fixed
Image sensor CMOS
Camera resolution / image sensor 640 x 480
Image frequency 30 / s
Display 3.5" TFT

Interface Mini USB 1.1 and AV out

Capture Picture and video

Memory SD card (incl.)

Compression format MPEG4

Image formatJPEG (640 x 480)Video output formatNTSC & PALVideo formatASF (320 x 240)Menu navigationMultilingual

Operating and storage 0 ... 60°C / 32 ... 140°F

temperature

Power supply Rechargeable 3.7V Li-Ion battery

Dimensions 207 x 118 (79) x 37 mm / 8.15 x 4.65 (3.11) x

1.46 in

Weight Approx. 450 g (1 lb)

More information

Manual

More product info



Similar products

