

# Condition Monitoring Device PCE-TG 300-NO5-ICA incl. ISO calibration certificate



## Condition Monitoring Device

**Large measuring range / Up to 600 mm / Pulse-echo or echo-echo mode / For all homogeneous materials / Print function via Bluetooth / USB connection**

The PCE-TG 300-NO5 is a condition monitoring device with special sensors for various applications. In general, the wall thicknesses of all homogeneous materials can be measured with the thickness meter. For damping or scattering materials such as plastic or cast a special sensor is available. An angled 90° sensor also enables measurements at hard-to-reach measuring points. The speed of sound can be set freely on the thickness meter and thus adapted to a wide variety of materials.

The measured values are displayed directly on the easy-to-read TFT color display. Due to the internal memory, which can be read out via the optionally available software, different measuring points can be clearly stored. The non-destructive ultrasound measuring method enables the measurement even on end products. Thanks to the Echo-Echo working mode, even coated workpieces can be measured.

- ▶ Large measuring range
- ▶ Various sensors available
- ▶ Battery operation
- ▶ Error and voids detection
- ▶ Internal measurement data memory
- ▶ Print via Bluetooth
- ▶ incl. ISO calibration certificate

# Specifications

## PCE-TG-NO5 sensor

Measuring range	<b>1 ... 600 mm / 0.039 ... 23.62" (steel)</b>
Minimum diameter of pipes	20 x 3 mm / 0.787 ... 0.118"
Frequency	5 MHz
Diameter	10mm / 0.39"
Description	normal measurement

## PCE-TG 300-NO5 device

Measuring range	P-E: pulse-echo mode 0.65 ... 600 mm / 0.025 ... 23.62" (steel) E-E: Echo-Echo mode 2.50 ... 100 mm / 0.098 ... 2.36"
Accuracy	±0.04 mm H[mm] (<10 mm); ±0.4 % H[mm] (>10 mm) H refers to the material thickness of the workpiece
Resolution	0.1 mm / 0.01 mm / 0.001 mm (adjustable)
Measurable materials	metals plastics ceramics epoxy resin glass and all homogeneous materials
Working modes	Pulse-echo mode (fault and void detection) Echo-echo mode (hide layer thicknesses, e.g. paint)
Calibration	sound velocity calibration zero calibration two-point calibration
View Mode	Normal Mode, Scan Mode, Difference Mode
Units	mm / inch
Data transfer	printing via Bluetooth / USB 2.0
Memory	non-volatile memory with 100 data groups with 100 data sets each
Operating time	continuous operation 100 h automatic stand-by mode (adjustable) auto power off mode (adjustable)
Power supply	4 x AA battery 1.5 V
Display	320 x 240 pixels TFT LCD color display with brightness adjustment
Operating conditions	0 ... +50 °C / 32 ... 122 °F, ≤80 % RH non-condensing
Storage conditions	-20 ... +70 °C / -4 ... 158 °F, ≤80 % RH non-condensing
Dimensions	185 x 97 x 40 mm / 7.2 x 3.8 x 1.5"
Weight	375 g / 13.2 oz

# More information

Manual



Video



More product info



Similar products



Subject to change