

DIGITAL REFRACTOMETER

PCE-DRD 1



- » **quick and accurate measurement in approx. 1 s**
- » **large LC display (measured value and temperature)**
- » **easy to use (1-key operation)**
- » **small sample volume**
- » **simple calibration with distilled water**
- » **automatic temperature compensation**
- » **stainless steel sample holder with glass prism**
- » **automatic power-off after 1 min of inactivity**

Our digital refractometer is a waterproof device and determines the percentage of sodium chloride in water with a measurement range of 0 to 28 % NaCl. The measurement result and the temperature of the sample are shown in two lines on the LCD display of the digital refractometer. The digital refractometer can measure various parameters such as salinity (%NaCl) and refractive index quickly and accurately with just four to five drops of the sample. The digital refractometer has a wide range of applications: checking the salt content in food, salt water tanks, brines, etc. It is ideal for the food industry for salt control and compliance with regulations.

The funnel-shaped stainless steel ring protects the glass prism from damage, into which the liquid sample to be measured is placed. The internal light source enables measurement under poor lighting conditions. Our digital refractometer is supplied in a rugged plastic case with pipette and charging cable.

Specification

Refractive index

Measurement range from 1,333 nD

Measurement range up to 1,42 nD

Resolution 0,0001 nD

Accuracy $\pm 0,0003$ nD

Salinity

Measurement range from 0 ‰

Measurement range up to 28 ‰

Resolution 0,1 ‰

Accuracy ± 0.2 ‰

Temperature

Measurement range from 0 °C

Measurement range up to 40 °C

Resolution 0,1 °C

Accuracy ± 0.5 °C

General technical data

Temperature compensation automatic 10 ... 40 °C

Display type LCD

Measuring rate 1 Hz

Automatic power-off 60 s

Sample quantity 0,2 ... 0,3 ml

Menu language English

Protection class (device) IP56

Power supply 5V DC, 500mA

Weight 115 g

Operating conditions 0 ... 50 °C, 0 ... 95 % r.F

Storage conditions 0 ... 50 °C, 0 ... 95 % r.F

Capacity 500 mAh

Dimensions (L x W x H) 145 x 46 x 27 mm