

UV STROBOSCOPE

PCE-LES 303UV-385-ICA



- » **3 high-power UVA LEDs**
- » **light colour: 365 ... 370 nm**
- » **flash frequency adjustable in FPM and Hz**
- » **intensity: 317 $\mu\text{W}/\text{cm}^2$ at 30 cm**
- » **digital pulse width modulation**
- » **phase shift: - 360 ° ... + 360 °**
- » **quick adjustment via x2 and \div 2 keys**
- » **intuitive control keys and clear display**
- » **pocket size**
- » **external trigger input and output**
- » **route measurement**

Analysing the movement of rotating machines is quick and easy with our stroboscope. The UV stroboscope is equipped with 3 high-power UVA LEDs, which together generate a light intensity of 317 $\mu\text{W}/\text{cm}^2$ at a distance of 30 cm. The stroboscope allows you to set the flash frequency in both FPM and Hz. The stroboscope is pocket-sized and also mains-independent thanks to the rechargeable battery.

The UV stroboscope is operated intuitively using the 10 keys, allowing quick adjustments to be made. The phase shift allows the observation point to be moved variably. The pulse width can be used to set the duration and therefore also the intensity of the flash frequency. The display brightness can be selected in the settings menu, as can switching off the display after a period of inactivity, which extends the battery life.

Specification

Frequency	
Measurement range up to	60 ... 9999,99 FPM
Resolution	0,01 FPM
Accuracy	±0.003 % of the setting or ±1 LSD
Frequency	
Measurement range up to	10000 ... 300000 FPM
Resolution	0,1 FPM
Accuracy	±0.003 % of the setting or ±1 LSD
Frequency	
Measurement range up to	1 ... 5000 Hz
Resolution	0,01 Hz
Accuracy	±0.003 % of the setting or ±1 LSD

General technical data	
Display type	LC colour display
Display size	2,8 Inch
Storage medium	Internal memory
Operating time	4,5 h
Operating time additional information	at flash frequency 100 Hz, 1 %, display brightness 70 %
Automatic power-off from...to	2 ... 10 min.
Automatic power-off can be deactivated	Yes
Luminous intensity	635 $\mu\text{W}/\text{cm}^2$ @ 20 cm @ 1000 Hz, 1 % 317 $\mu\text{W}/\text{cm}^2$ @ 30 cm @ 1000 Hz, 1 % 115 $\mu\text{W}/\text{cm}^2$ @ 50 cm @ 1000 Hz, 1 %
Light colour	UV light (380 ... 390 nm)
Phase shift	-360 ... 360 °
Pulse width	0.01 ... 1 % of pulse duration Resolution: 0.01 % 0.01 ° ... 3.60 ° of 360 ° Resolution: 0.01 °
Trigger input	Input: permitted input: NPN signal, 24 V DC, sensor supply: 24 V / 100 mA for external sensors Output: open-drain output, up to 24 V, 50 mA
Route measurement	Up to 15 routes, 10 machines per route, 5 points per machine
Menu language	Turkish, English, Polish, Spanish, German, Chinese, Russian, French, Italian, Dutch
Protection class (device)	IP52
Power supply	5 V DC, 2 A
(Rechargeable) battery	1 x 7,4 V internal, Lithium-ion battery
Capacity	2200 mAh
Operating conditions	-20 ... 60 °C, 35 ... 85 % RH
Storage conditions	-20 ... 60 °C, 35 ... 85 % RH
Dimensions (L x W x H)	165 x 90 x 35 mm
Weight	284 g