

FORCE GAUGE

PCE-DFG 2K XF-ICA



- » measurement range: 0 ... 2000 N
- » sampling rate: 1 ... 7,200 Hz
- » accuracy: ± 0.05 % FS
- » graphic display
- » USB-C interface
- » PC software (available soon)
- » 32 GB memory for 30 million measuring points
- » various alarm modes
- » bar chart displays reading within measurement range
- » calibration reminder
- » incl. ISO-Calibration Certificate

The force gauge with an external pressure load cell is designed for measuring compressive forces at measuring locations that are difficult to access. The force gauge or rather the pressure load cell has several threaded holes at the bottom that allow it to be mounted securely. The load cell is connected to the force gauge via an approx. 3 m long sensor cable and, thanks to the compact cell dimensions, it can be used for a wide range of applications.

The internal memory of 32 GB can hold 30 million measuring points. This allows measurement protocols to be created, saved and exported. The force gauge has a USB-C interface that can be used to import the measurement data into the PC software. The device is equipped with a graphic LCD that displays the measured values both numerically and graphically. In addition, a bar chart shows the measured value within the selected measurement range.

Specification

Force

Measurement range up to 0 ... 2000 N

Resolution 0,5 N

Accuracy $\pm 0.05\%$ FS

General technical data

Units N, kg, g, t, kn, Pa, kPa, Nm, Ncm, lb, ft

Display type LCD with backlight

Display size 2,8 Inch

Adjustable measuring rate 1 ... 7200 Hz

Storage medium Internal memory

Storage capacity 32 GB

Storage interval from 1 Hz

Storage interval to 7200 Hz

Interface USB-C

Operating time 13 h

Automatic power-off from...to 1 ... 15 min.

Automatic power-off can be deactivated Yes

Alarm optical, Acoustic

Alarm modes Within, beyond, fracture, off

Protection class measuring cell IP67

Menu language Turkish, English, Polish, Spanish, German, Chinese, Russian, Japanese, French, Danish, Italian, Dutch, Portuguese

Protection class (device) IP52

Power supply USB 5 V DC, 500 mA

Capacity 2200 mAh

Operating conditions -20 ... 65 °C, 10 ... 95 % RH

Storage conditions -20 ... 65 °C, 10 ... 95 % RH

Dimensions (L x W x H) 165 x 85 x 32 mm

Other dimensions Pressure load cell \varnothing 32 mm / H 16 mm / M5 thread

Weight 275 g

Other weights Pressure load cell: 116 g