

Technical Specification Stethoscope PCE-S 42

Machine Stethoscope PCE-S 42

**Machine stethoscope to listen to bearings and motors /
two measuring tips of different lengths / 32 sound levels /
noise-suppressing headphones included in delivery /**

The machine stethoscope PCE-S 42 is designed for listening to individual machine parts, which enables you to carry out maintenance and repair work using the machine stethoscope. The use of a machine stethoscope thus makes it easier to listen to sound phenomena in bearings and motors. This makes it possible to amplify noises that imply that the machine is slightly damaged, which can cause severe impairments and damage to the machine if not observed. The machine stethoscope comes with headphones the shape of which is adapted to the human head and thus is perfectly suitable to be used in noisy environments. The big, padded earpieces have a noise-suppressing effect and at the same time offer high wearing comfort. The machine stethoscope is most frequently used to amplify knocking and grinding noises. When these noises occur, it is urgently necessary to maintain the machine tested thoroughly and, if necessary, replace individual parts to prevent financial losses due to machine downtime.

- two different measuring tips
- non-stationary measuring device
- 32 volume levels
- headphones adapted to the human head
- for preventive maintenance and servicing
- noise-suppressing headphones

Technical Specifications

Frequency range	30 Hz ... 150 KHz
Operating temperature	-10 ... +40 °C
Output volume	digitally adjustable (32 levels)
Headphones	32 Ω
Power supply	4 x AAA battery
Battery life	30 h
Dimensions	220 x 35 x 35 mm
Length sensors	70 / 280 mm

Delivery contents

1 x machine stethoscope PCE-S 42, 1 x headphones, 1 x long measuring tip, 1 x short measuring tip, 6 x AAA batteries, 1 x carrying case with shoulder strap, 1 x instruction manual