

## Technical Crane Scales PCE-HS 150N

### PCE-HS 150N Crane Scale

#### Digital, battery-operated hanging scale with weight range up to 150 kg / 330 lbs

PCE-HS 150N is an affordable digital hanging scale, crane scale, weighing hook or electronic balance that offers quick, easy and accurate weighing of large objects, animals, fish and game. Simply mount the item to be weighed to the hook or snap hook (both hooks are included). Useful for forklift and industrial applications and as well as recreational fishing and hunting, the PCE-HS 150N digital hanging scale features:

- Weight range up to 150 kg / 330 lbs
- Battery operation (3 x AA 1.5 V batteries provided)
- Auto-off, power-saving function (can be deactivated, if preferred)
- Multiple, full-range tare (useful when adding weighing objects or for the production of mixtures)
- PEAK hold function and measurement conversion to Newton (N) (enables use as a simple force meter)
- Animal weighing function (calculates an average of several values, allowing live animal weighing)

#### Technical specifications

Maximum allowable load	150 kg / 150000 g / 330 lbs
Minimum load (no display)	0.50 kg / 500 g / 1.10 lbs
Readability (d)	0.05 kg / 50 g / 0.11 lb
Tolerance / Accuracy PCE-HS 150 N	± 0.20 kg / 200 g / 0.44 lb
General information	
Tare	Multiple, full-range tare
Display	LCD illuminated
Digit	19 mm / 0.75 in
Units of measurement	kg / lb / N (Newton)
Power supply	3 x 1.5 V AA batteries (included)
Operating temperature	5 °C ... 35 °C / 41 °F ... 95 °F
Housing	ABS plastic
Weight	Approx. 0.40 kg / 400 g / 0.88 lb

#### Delivery contents

- 1 x digital hanging scale
- 3 x AA 1.5 V batteries
- 1 x hook
- 1 x snap hook
- 1 x user manual