

**Hygrometer to measure temperature and humidity / Internal sensor /
Additional: Determination of dew point and wet bulb temperature / Data-Hold function /
Min, Max and Average function / battery saving function**

As a universal temperature and humidity gauge, the Hygrometer PCE-TH 5 enables the measurement of ambient temperature, humidity, dew point and wet bulb temperature. The Hygrometer measures the temperature and humidity via an internal sensor which allows the calculation of the dew point and wet bulb temperature. Because of the data-hold function you can store a measurement in the display. The easy to read display also shows the Min, Max and Average measurement. The Hygrometer PCE-TH 5 is powered with a long-life lithium battery with automatic cutout after 15 minutes of inactivity.

- For temperature and humidity
- Data-Hold function
- Internal sensor
- Min, Max and Average function
- Battery saving function
- Dew point and wet bulb temperature

Technical data for the Hygrometer PCE-TH 5

Temperature measuring range	-20 ... +50 °C
Resolution	0.1 °C
Accuracy	±0.6 °C
Humidity measuring range	0 ... 99.9% r.H.
Resolution	0.1% r.H.
Accuracy	±3% (25 °C, 10 ... 90%), otherwise 5% r.H.
Operating temperature	-20 ... +50 °C, <80 % r.H.
Power supply	CR2032 lithium battery
Dimensions	135 x 18 x 36.3 mm

Delivery content of the Hygrometer PCE-TH 5

1 x Hygrometer PCE-TH 5, 1 x CR2032 lithium battery, 1 x user manual