

PCE Americas Inc. 711 Commerce Way Suite 8 Jupiter FL-33458 USA From outside US: +1 Tel: (561) 320-9176 info® pce-americas.com www.pce-instruments.com/us

PCE Instruments UK Ltd. Units 12/13 Southpoint Business Park Ensign way Hampshire / Southampton United Kingdom, SO31 4RF From outside UK: +44 Tel: (0) 2380 98703 9 inflo@industrial-needs.com www.pcei-ristruments.com/english

www.industrial-needs.com

TEMPERATURE AND HUMIDITY TRANSDUCER PCE-P18



USER'S MANUAL

CE

1

Contents

1. APPLICATION	5
2. TRANSDUCER SET	7
3. BASIC REQUIREMENTS, OPERATIONAL SAFETY	7
4. INSTALLATION	7
4.1. Way of fixing	7
4.2. External connection diagrams	9
5. SERVICE	11
5.1. Power-on messages of the P18D transducer	11
5.2. Description of the P18D transducer readout field	12
5.3. Functions of the P18D transducer capacitive button	13
5.4. Programming parameters menu of the P18D transducer.	14
5.5. Functions of the P18(D) transducer	15
5.5.1. Calculated values	16
5.5.2. Selection of controlling values for analog outputs	16
5.5.3. Individual characteristic of analog outputs	17
5.5.4. Support of a sensor heater	19
5.5.5. Default settings	20
6. RS-485 INTERFACE	21
6.1. Connection of the serial interface	21
6.2. Description of the MODBUS protocol implementation	23
6.3 Description of the functions used	23
6.4 Map of the registers	26
6.5 Registers for writing and readout	27
6.6 Registers for readout	33
6.7 Emergency restoration of default parameters	36
7. ERROR CODES	37
8. ACCESSORIES	38
9. TECHNICAL DATA	39
10. ORDERING CODE	41

1. APPLICATION

The PCE-P18 transducers are the devices destined for the continuous measurement and conversion of relative humidity and ambient temperature into a digital form and into a voltage or cur-rent standard signal. The transducers are fixed on a wall. Programming of the transmitters is possible via the RS?-485 interface. LPCon or eCon software designed for configuration of the transducers is available on the manufacturer's website: www.pce-instruments.com. Applied sensor shields enable the application of the transducers in various ambient conditions.



Fig. 1. Overview of the P18 and P18D transducers with the probe on the housing.



Fig. 2. Overview of the P18 and P18D transducers with the probe on the wire 0,5 m.

2. TRANSDUCER SET

-	Transducer	1 pc
-	User's manual	1 pc
-	Warranty card	1 pc

3. BASIC REQUIREMENTS, OPERATIONAL SAFETY

In terms of operational safety, the transducer meets the requirements of the EN 61010-1 standard.

Comments concerning safety



- Assembly and installation of the electrical connections should conducted only by people authorised to perform assembly of electric devices.
- Always check the connections before turning the transducer on.
- The transducer is designed to installation and usage in the industrial electromagnetic environment.

4. INSTALLATION

4.1. Assembly

The P18(D) transducer is designed to be mounted on a wall by means of a screw connection or glue without the loss of IP65 tightness. The transducer housing is made of a self-extinguishing plastics. The transducer has screw connectors placed inside the transducer, which enable the connection of external wires of 1 mm² cross-section.



Fig. 3. Overall dimensions of the P18(D) transducer



Fig. 4. Lay-out of mounting holes of the P18(D) transducer

8

4.2. External connection diagrams

The P18(D) transducer version P18(D)-1XXX or P18(D)2XXX has 8 connecting terminals, version P18(D)-0XXX has 4 terminals (version without analog outputs). Access to the terminals is possible after removing the cover of the transducer housing. You should use a multi-conductor round wire with external diameter from 3.5 mm up to 6 mm for electrical connections. Remove the display prior to connecting the wires in a screw terminal of the P18D transducer. Pass supplying wires through the packing and twist the packing seal in order to obtain the leaktightness. If the packing seal is not twisted, the required IP 65 leaktightness is not ensured. The LCD display should be put back after screwing the wires to the screw terminal of the P18D transducer.



Fig. 5. Marking of the terminals for the connection of external signals of the P18(D) transducers in versions: a) without analog outputs, b) with analog outputs.



Fig. 6. Wiring diagram of the P18(D) transducer with analog outputs

Use shielded cable for supply and output signals in environments with high levels of interference. The shield must be connected to the nearest PE point from the feeder side.

5. SERVICE

The P18D transducer is equipped with a display field 8x2 characters with illumination and one capacitive button located on the housing. The P18 transducer is not equipped with a display or a button. After connecting the wires, closing and servicing the housing, and connecting to the supply, the transducer is ready to work with manufacturer's settings (Tab. 4). The transducer can be programmed through the RS-485 interface. You can program following parameters in the transducer:

- communication parameters
- - averaging time of the measurement
- - individual characteristics of analog outputs (for executions with analog outputs).

The P18D transducers allow programming communication parameters (address, baud rate, mode) using the capacitive button.

There is the possibility to connect the transducer through another transmission media, like: ETHERNET, USB using LUMEL S.A.'s converters.

5.1. Power-on messages of the P18D transducer

After connecting the external signals and connecting to the supply, the transducer displays the type, current program version, serial number and set communication parameters (address, baud rate and operating mode).

The transmitter automatically switches to the operating mode of measurement and processing the analog output signal after approx. 5 seconds. It displays the measuring value with the unit in the bottom line of the display, the top line of the display contains information about the type of displayed quantity and the pictograms of: transmission via RS-485, the presentation mode of the measuring value, the read pointer of the measuring value of the sensor and the operating state of the internal heater.

5.2. Description of the P18D transducer readout field

The illuminated character LCD is a readout field in the transducer P18D. The illumination is turned on after switching on the supply and after the capacitive button on the housing is pressed. The illumination is automatically switched off after 30 sec. of inactivity.



Fig. 7. Description of the P18D transducer readout field

Description of the symbols displayed by the P18D transducer is in the Table 1.

Та	bl	le	1
	~ .		

Symbol	Meaning							
T:	Type of the displayed value in the bottom line of the LCD - temperature							
RH:	Type of the displayed value in the bottom line of the LCD - relative humidity							

DP:	Type of the displayed value in the bottom line of the LCD - dew-point							
AH:	Type of the displayed value in the bottom line of the LCD - absolute humidity							
×	The indicator of the measuring value from the sensor							
A	Automatic mode of measurement results presentation - a type of displayed value is automatically switched every 3 seconds in the following order: temperature \rightarrow relative humidity \rightarrow dew-point \rightarrow absolute humidity \rightarrow temperature							
R	Data receiving indicator by the P18D transducer on RS-485							
Т	Data sending indicator by the P18D transducer on RS-485							
h	Switching on the internal heater indicator to dry the sensor							

5.3. Functions of the P18D transducer capacitive button

The P18D transducers are equipped with one capacitive button located on the housing. The location of the button shows in Fig. 8.



Fig. 8. Location of the P18D transducer capacitive button

Capacitive button is used to:

- switch the display illumination on
- change the presentation mode of the measurement results holding the button for about 2 seconds switches from automatic mode to manual mode or inversely
- change the type of displayed values in the manual mode of presentation of the measurement results - pressing the button for a short time changes the displayed value.
- program communication parameters (address, baud rate, mode)

5.4. Programming parameters menu of the P18D transducer

Enter the programming menu by pressing and holding the capacitive button for approx. 5 sec. When entering the menu a first time, changes direction marker is set to $\bullet^{\bullet\bullet}$. - increasing the value; next entry in the menu will cause the cyclic switching of the direction of changes (2 input in the menu will set the marker at \vee – decreasing the value). If the idle time exceeds 20 seconds, the transducer will leave the menu and switch to displaying the measuring value.







Fig. 10. Programming parameters algorithm of the P18D transducer

5.5. Functions of the P18(D) transducer

The P18(D) transducer carries out the functions:

- · measurement of the ambient temperature and relative humidity
- calculation of chosen physical quantities (dew-point temperature, absolute humidity, wet bulb temperature)
- conversion of measured values into an output signal on the base of the individual linear characteristic (2 configurable analog outputs - optional)
- memory storage of maximal and minimal values for each of the measured and calculated value
- · programming of the measurement averaging time
- RS-485 interface servicing in the MODBUS protocol, in RTU mode.
- Displaying measuring and calculated values (only P18D)

5.5.1. Calculated values

Based on the measurement of a temperature and relative humidity, the P18D transducer calculates dew-point and absolute humidity of the following dependencies.

DP
$$\rightarrow$$
 dwe-point:

$$DP = \frac{T_n}{\frac{m}{\log\left(P_{ws} \cdot \frac{RH}{1000 \cdot A}\right)}} - 1$$

 $DP \rightarrow absolute humidity:$

$$AH = 2,1668 \cdot \frac{P_{_{WS}} \cdot RH}{100 \cdot (T + 273.2)}$$

gdzie:

 $T \rightarrow$ measured temperature [°C]

 $RH \rightarrow$ measured absolute humidity [%]

 $DP \rightarrow$ dew-point temperature [°C]

 $P_{ws} \rightarrow \text{saturated water vapor pressure (water vapor pressure) [mbar]}$

 $AH \rightarrow$ absolute humidity [g/m³]

Table 2

The factors used to calculate the dew-point								
T [°C] A m T _n								
< 0	6.119866	7.926104	250.4138					
050	6.1078	7.5	237.3					
50100	5.9987	7.3313	229.1					

5.5.2. Selection of controlling values for analog outputs

The P18(D) transducers in versions P18(D)-1XX, P18(D)-2XX, P18(D)-4XX, P18(D)-5XX are equipped with two programmable analog outputs (voltage or current). By default, the first analog output is set for a presentation of the ambient temperature and the second analog output is controlled by the value of the relative humidity. The analog outputs can respond to any of the measuring or calculated values (T, RH, DP, AH, wet bulb temperature). The value controlling the analog outputs is defined by the registers, respectively 4015 for the first output and 4016 for the second analog output (Tab. 14).

5.5.3. Individual characteristic of analog outputs

The P18(D) transducers in the version with analog outputs enable the conversion of measured values into an output signal based on the strength of individual linear characteristic of analog outputs. On the base of given coordinates of two points by the user, the transducer determines (from the system of equations) coefficients a and b of the individual characteristic.

$$\begin{cases} Ylout = a \cdot Xlin + b \\ Y2out = a \cdot X2in + b \end{cases}$$

where:

X1 in and X2 in - displayed value,

YI out and Y2 out - oexpected value of the analog output



Fig. 11. Individual characteristic of analog output

The configuration of the individual characteristic of analog outputs amounts to the introduction of suitable values X1, X2, Y1, Y2 in corresponding registers to them from the range 4007 – 4014 Tab. 3. The values introduced in these registers must be integral values corresponding to the set point values multiplied by the value 100.

Example 1

Configuration of the individual characteristic of the first analog current output (temperature):

Expected processing temperature in the range -12,25°C \div 77,75 °C to the analog current signal in the range 4,5 mA \div 18,5 mA.

Table 3

Name	Register address	Value
X1 temperature	4007	-1225
Y1 current	4008	450
X2 temperature	4009	7775
Y2 current	4010	1850

Caution:

The analog outputs are not isolated from the supply, the RS-485 interface and each other, the analog current outputs don't have a common potential (low potential terminals can not be connected together), analog voltage outputs have a common low potential (low potential terminals can be connected together).

5.5.4. Support of a sensor heater

The sensors used in the P18(D) transducers are equipped with internal heating elements to allow faster release of water molecules from the sensor being flooded or working a long time in highly humid environments. Switching the heater on is possible by writing the appropriate value to the register 4021 (see Tab. 14). Status of the heater is available in the status register (register 4017) at the bit position 11 (if the bit 11 of the register 4017 is set to "1" - this means that the heater is switched on).

Caution:

The transducer with a heating element switched on does not measure the proper ambient temperature and humidity! (the temperature measured by the sensor increases and the humidity decreases). The value 200 is added to the measuring values (temperature, relative humidity) when using the transducer with the heater switched on in order to avoid distortions of a measurement in the measurement systems!

The P18D transducers working with a heating element switched on display a flashing symbol h.

Fig. 12. Indication of the P18D transducer operation with a heater switched on

5.5.5. Default settings

The Table 4 shows the standard settings of the P18D transducer. The settings can be restored via the RS-485 interface after writing the value $_{1}^{1}$ to the registry 4020.

D (Para-		Standard value				
Parameter description	meter address	P18D-0XX, P18D-3XX	P18D-1XX, P18D-4XX	P18D-2XX, P18D-5XX			
Address	4001	1					
Baud rate	4002		9600				
Mode	4003		RTU 8N2				
Averaging time	4005		30 [s]				
X1 of the 1st analog output	4007	0	0 -2000				
Y1 of the 1st analog output	4008	0 400		0			
X2 of the 1st analog output	4009	0 6000		6000			
Y2 of the 1st analog output	4010	0	1000				
X1 of the 2nd analog output	4011	0 0		0			
Y1 of the 2nd analog output	4012	0 400		0			
X2 of the 2nd analog output	4013	0	10000				
Y2 of the 2nd analog output	4014	0 2000 1000					

Value control- ling the first analog output.	4015	0	0	0
Value control- ling the second analog output.	4016	1	1	1
Custom confi- guration	4019	8	8	8

6. RS-485 INTERFACE

The P18(D) programmable digital transducers have a serial link RS-485 for communication in the computer systems and with other devices that serve as a Master. Asynchronous character MODBUS communication protocol has been implemented in a serial link. The transmission protocol describes how to exchange information between devices via a serial link.

Caution:

For the transmitter versions without analog outputs (P18 (D) -0XX and P18 (D) -3XX), the RS-485 interface is galvanically isolated from the supply - 1 kV separation.

For the transmitter versions with analog outputs, the RS-485 interface is not isolated from the supply or from the analog outputs.

6.1. Connection of the serial interface

Standard RS-485 allows a direct connection up to 32 devices on a single serial link to a length of 1200 m (at baud rate 9600 b/s). It is necessary to use additional intermediate-separation circuits for connecting higher number of the devices, for example PD51 manufactured by LUMEL S.A. Output of the interface line is shown in Fig. 6. It is required to connect the lines A and B in parallel with their equivalents in other devices to obtain the correct transmission. The connection must use a shielded wire. The cable shield should be connected to the protective terminal in close proximity to the transmitter (connect a shield to the protective terminal at one point only).

RS-485 interface card or the converter is required for a connection to a PC, for example PD10. The method of connecting devices is shown in Fig. 13.



Fig. 13. Connecting the RS-485 interface.

6.2. Description of the MODBUS protocol implementation

The implemented protocol is compliant with the PI-MBUS-300 Rev G specification of Modicon.

Set of parameters of the P18D transducer serial link in the MODBUS protocol:

- Transducer address 1..247.
- Baud rate: 4800, 9600, 19200, 38400, 57600, 115200 [b/s].
- Operating mode: RTU frame format: 8N2, 8E1, 8O1, 8N1.
- Maximum response time: 500 ms

Configuration of the serial link parameters consists of determining the baud rate, the device address and the format of the transmission mode - protocol.

Caution: Each transmitter connected to the communication network must:

- have a unique address, different from the addresses of other devices connected to the network.
- · Identical baud rate and type of a transmission mode

6.3 Description of the functions used

Following functions of the MODBUS protocol have been implemented in P18D transducers:

- 03 (03h) readout of registers group,
- 04 (04h) readout of input registers group,
- 06 (06h) single register writing,
- 16 (10h) registers group writing,
- 17 (11h) slave device identification.

Example 1. Readout of 2 registers, starting with the register address 1D4Dh (7501) float (32-bit), (register values 25.68, 20.25.)

Request:

Table 5

Device	Function	Register address		Number of registers		CRC check-
address	address		B0	B1	B0	sum
01h	03h	1Dh	4Dh	00h	02h	5270h

Response:

Table 6

Device ad-	Fun-	Num- ber of 1DB0 (7501)			Value from the register 1DB1 (7502)				CRC check-		
dress ction bytes	B3	B2	B1	B0	B3	B2	B1	B0	sum		
01h	03h	08h	41h	CDh	70h	A4h	41h	A2h	00h	00h	83D0h

Single register writing (code 06h)

Example 2. Writing the value 78h (120) to the register FA1h (4001)

Request:

Table 7

Device	Function	Register address Register value		CRC		
address		B1	B0	B1	B0	checksum
01h	06h	0Fh	A1h	00h	78h	DB1Eh

Response:

Device	Function	Register	address	Registe	CRC	
address	1 dilotori	B1	B0	B1	B0	checksum
01h	06h	0Fh	A1h	00h	78h	DB1Eh

Writing n-registers (code 10h)

Example 3. Writing the value 78h (120) and the value 4h (4) to the registers FA1h, FA2h (4001, 4002)

Request:

De- vice ad-	Fun- ction	Reg addi	ister ress	Numb regis	ber of sters		Num- ber of 4001		Register value 4002		CRC check-
dress				9		bytes	B1	B0	B1	B0	sum
01h	10h	0Fh	A1h	00h	78h	04h	00h	78h	00	04	F831h

Response:

Table 10

Device	Eunction	Register	address	Number of	CRC	
address	1 unotion	B1	B0	B1	B0	checksum
01h	10h	0Fh	A1h	00h	02h	133Eh

Device identification report (code 11h)

Example 4. Device identification

Request:

Table 11

Device address	Function	Checksum
01h	11h	C02Ch

Response:

Table 12

Device ad- dress	Fun- ction	Num- ber of bytes	Identi- fier P18D	De- vice status	The field depending on the device software version (e.g. 0.70)	CRC check- sum
01h	11h	0Eh	CCh	FFh	50h 31h 38h 44h 76h 2Eh 30h 2Eh 30h 34h 20h 00h	B154h

6.4 Map of the registers

In the P18D transducer, data are placed in 16 and 32-bit registers. Process variables and transducer parameters are placed in the address area of registers in a way depended on the variable value type. Bits in 16-bit registers are numbered from the youngest to the oldest (b0 ... b15). The 32-bit registers (4 bytes) contain numbers of float type in IEEE-754 standard. Bytes sequence: B3 B2 B1 B0 – the oldest byte is transmitted as the first.

A following map is the map of P18(D) transducers registers.

Caution:

All listed addresses are physical addresses. Some computer programs use logic addressing, then the addresses should be increased by 1.

Address range	Value type	Description
4000-4022	integer (16 bits)	The value is located in the 16-bit register.
6000-6030	float (32 bits)	Value set in the two following 16-bit registers. These registers contain the same data as 32-bit registers from 7500-7515 range. Readout registers. Bytes sequence (B1,B0,B3,B2)
7000-7030	float (32 bits)	Value set in the two following 16-bit registers. These registers contain the same data as 32-bit registers from 7500-7515 range. Readout registers. Bytes sequence (B3,B2,B1,B0)
7500-7515	float (32 bits)	The value is located in the 32-bit register. Registers contain measured and calculated data by the transducer. Registers are only for readout.

6.5 Registers for writing and readout

The value is located in the 16-bit registers	Name	Write (w) / readout (r)	Range	Description		
4000	Identifier	w/	180	P18 d	evice identifier	
		r	204	P18D	device identifier	
4001	Address	w/ r	1247	Device address		
4002	RS-485 baud rate		05	Va- lue	Description	
				0	4800 bit/s	
				1	9600 bit/s	
				2	19200 bit/s	
				3	38400 bit/s	
				4	57600 bit/s	
				5	115200 bit/s	
4003	RS-485 transmis-		03	Va- lue	Description	
	sion mode			0	RTU 8N1	
				1	RTU 8N2	
				2	RTU 8E1	
				3	RTU 801	

4004	Confir- mation		01	Va- lue	Description
	of trans- mission			0	No change
	parameters changes			1	Confirmation of changes
4005	Averaging time	w/ r	63600	Avera surem	ging time of the mea- ent [s]
4006	Erasing the extre-	w/ r	01	Va- lue	Description
	mes			0	No change
				1	Erasing the min. and max. values
4007	X1 of out- put 1	w/ r	-32768 32767	ts	Value controlling out- put 1 - point X1[x100]
4008	Y1 of out- put 1	w/ r	-32768 32767	outpu	Expected value of output 1 for point X1
4009	X2 of out- put 1	w/ r	-32768 32767	analog	Value controlling output 1 - point X2 [x100]
4010	Y2 of out- put 1	w/ r	-32768 32767	tic of a	Expected value of output 1 for point X2
4011	X1 of out- put 2	w/ r	-32768 32767	acteris	Value controlling output 2 - point X1 [x100]
4012	Y1 of out- put 2	w/ r	-32768 32767	al chan	Expected value of output 2 for point X1
4013	X2 of out- put 2	w/ r	-32768 32767	dividua	Value controlling output 2 - point X2 [x100]
4014	Y2 of out- put 2	w/ r	-32768 32767	<u> </u>	Expected value of out- put 2 for point X2
4015	Value controlling	w/ r	03	Va- lue	Description
	1 analog			0	Temperature
	ouput.			1	Relative humidity

				2	Dew-point	
				3	Absolute humidity	
				4	Wet bulb tempera- ture	
4016	Value controlling	w/ r	03	Va- lue	Description	
	2 analog			0	Temperature	
	output			1	Relative humidity	
				2	Dew-point	
				3	Absolute humidity	
				4	Wet bulb tempera- ture	
4017	Status	w/ r	-32768 32767	Transducer status. Shows the current state of the trans- ducer and the hardware con- figuration. Successive bits represent the event. Bit set to 1 indicates that the event took place		
				Bit15 Restart of the sup ly, writing the valu -32768 (8000h) w clear the status bit		
				Bit14	Error of the calibra- tion parameters	
				Bit13	Error of the transmit- ter settings - enter the new settings	

	Bit12	not u	ised		
	Bit11	Indic the h	ator o leater	f switc on	hing
	Bit10	Indic the e the v erase	ator extrem alue 1 es the	of era les, w 024 (4 status	asing riting 00h) s bit
	Bit9	Temp nicat are s per "	oorary ion p set (sh ZW")	con param orten	nmu- eters jum-
	Bit8	LCD	display	error	
	Bit7	Erroi lue fi	readi om th	ing the	e va- sor
	Bit5, 6	Value anale	e cor og out	ntrollin put	g 2
		00	01	10	11
		temperature	relative humidity	dew-point	absolute humidity
	Bit3, 4	Value anale	e cor og out	ntrollin put	g 1
		00	01	10	11
		temperature	relative humidity	dew-point	absolute humidity
		Bit12 Bit11 Bit10 Bit9 Bit8 Bit7 Bit5, 6 Bit5, 4	Bit12not uBit11Indic the hBit10Indic the e erassBit9Temp nicat are s per ,Bit8LCDBit7Error lue frBit5, 0Value anale00Bit3, 4Value anale00support up up	Bit12 not used Bit11 Indicator of the heater Bit10 Indicator of the extremente value 1 Bit10 Indicator of the extremente value 1 Bit9 Temporary nication per "ZW") Bit8 LCD display Bit7 Error readilue from the sale out of the extremente value 1 Bit8 LCD display Bit7 Bit8 Bit8 LCD display Bit7 Error readilue from the sale out of the extremente value 1 Bit7 Bit8 Bit8 LCD display Bit7 Value cor analog out 00 00 01 Bit3, 4 Value cor analog out 00 00 01 Bit3, 4 Value cor analog out 00 00 01 Bit3, 4 Value cor analog out 00 00 01 Bit9 Value cor analog out 00 Bit9 Value cor analog 0 Bit9 Value cor analog 0	Bit12 not used Bit11 Indicator of switch the heater on Bit10 Indicator of erathe extremes, with value 1024 (4 erases the status Bit9 Temporary connication paramare set (shorten per "ZW") Bit8 LCD display error Bit7 Error reading the lue from the sens Bit5, 6 Value controllin analog output 00 01 10 Bit3, 4 Value controllin analog output 00 01 10 Bit3, 4 Value controllin analog output 00 01 10 Bit3, 4 Value controllin analog output 00 01 10 Bit3, 4 Value controllin analog output 00 01 10 Bit3, 4 Value controllin analog output 00 01 10 Bit3, 4 Value controllin analog output 00 01 10 Bit3, 4 Value controllin analog output 00 01 10 Bit3, 4 Value controllin analog output 00 01 10 Bit3, 5 <t< td=""></t<>

				Bit2	results ave terval has	eraging in- ended
				Bit1	The transdu pped with outputs - vo	ucer is equi- the analog oltage.
				Bit0	The transdu pped with outputs - cu	ucer is equi- the analog urrent.
4018	Software version	0	1999	Softwa	are version >	(100
4019	Custom configura-	w/ r	031	Bit0	Value	Descrip- tion
	tion				0	The stan- dard map of the re- gisters in the range 7000 and 7500
					1	Map of the regi- sters in the ran- ge 7500 and 7000 compliant with the map of the P14W transdu- cers
				Bit1 4	Number of of a respo to the que RS-485 tra	characters onse delay ery for the ansmission

4020	Default	w/	01	Va-	Description
	settings	r		lue	
				0	no change
				1	przywraca parametry fabryczne
4021	Controlling the heater			Va- lue	Description
				0	switching a heater off
				1	permanent switching a heater on
				3	displaying remaining time of a heater swit- ched on
				60 32768	switching a heater on for Xn seconds (Xn - value from the range 6032768)
4022	reserved				

Value set in the two following 16-bit registers. Registers contain the same data as 32-bit registers from the area 7500.	The value is located in the 32-bit registers	Name	Write (w)/ readout (r)	Unit	Quantity name
7000	7500	ID	r	-	P18(D) device identifier
7002	7501	Т	r	°C	Measured temperature
7004	7502	RH	r	%	Measured relative humidity
7006	7503	DP	r	°C	Calculated dew-point
7008	7504	AH	r	g/m ³	Calculated absolute humi- dity
7010	7505	min T	r	°C	Min. of temperature
7012	7506	max T	r	°C	Max. of temperature
7014	7507	min RH	r	%	Min. of relative humidity
7016	7508	max RH	r	%	Max. of relative humidity
7018	7509	min DP	r	°C	Min. of dew-point

6.6 Registers for readout

7020	7510	max DP	r	°C	Max. of dew-point
7022	7511	min AH	r	g/m ³	Min. of absolute humidity
7024	7512	max AH	r	g/m ³	Max. of absolute humidity
7026	7513		r	°C	Wet bulb temperature
7028	7514		r	kPa	Water vapor pressure

Table 16 shows the registers of measuring values of the P18D transducer working in the registers 7000 and 7500 compatibility mode with the P14W transducer

Value set in the two following 16-bit registers. Re- gisters contain the same data as 32-bit registers from the area 7500.	The value is located in the 32-bit registers	Name	Write (w) /readout (r)	Unit	Quantity name
7000	7500	ID	ο	-	P18(D) device iden- tifier

7002	7501	т	0	°C	Measured tempera- ture		
7004	7502	DP	0	°C	Calculated dew-point		
7006	7503	-	-	-			
7008	7504	RH	о	%	Measured relative humidity		
7010	7505	AH	0	g/m ³	Calculated absolute humidity		
7012	7506	-	-	-			
7014	7507	-	-	-			
7016	7508	-	-	-			
7018	7509	min T		°C	Min. of temperature		
7020	7510	max T		°C	Max. of temperature		
7022	7511	min DP		°C	Min. of dew-point		
7024	7512	max DP		°C	Max. of dew-point		
7026	7513	-	-	-			
7028	7514	-	-	-			
7030	7515	min RH	o	%	Min. of relative humidity		
7032	7516	max RH	0	%	Max. of relative humidity		
7034	7517	min AH	ο	g/m ³	Min. of absolute humidity		
7036	7518	max AH	0	g/m ³	Max. of absolute humidity		

6.7 Emergency restoration of default parameters

If the communication parameters have been changed and the new configuration is lost, you can use the jumper marked "ZW" on the transmitter's board to set the temporary communication parameters:

- address 247
- baud rate
 9600 kb/s
- mode RTU 8N2

You can connect to the transmitter after setting the temporary parameters and adjust them or restore the defaults settings. After removing the jumper, the transducer returns to previous settings or to settings changed during the operation with the jumper.



Fig. 13. Placement of the jumper setting temporary communication parameters

7. ERROR CODES

The error messages could be displayed on the transducer P18D display during operation. The table below lists the error codes which are possible to be displayed and their reasons as well as the recommended user responses. Information about the existing errors is also available in the P18(D) transducers status register - register 4017.

Message	bit no. reg. Status (reg. 4017)	Description
Error Sensor	7	Sensor failure - transmitter should be returned to a service
Error Calibr.	14	Loss of calibration parameters - loss of efficiency of the analog outputs, measurements are correct - returning a transmitter to a service should be considered
Error Param. XX	13	Loss of transmitter settings - XX - number of a parameter (register number 40XX) configured incorrectly - correct value should be written to the register 40XX or default settings restored

8. ACCESSORIES

As a standard, the P18(D) transducer is equipped with a shield of the sensor, destined only for indoors applications. It is recommended to use additional shields of the sensor (interchangeable) for outdoors or indoors applications exposed to the possibility of water vapor condensation, depending of the transducer working conditions.

Item	Order code	Dra- wing	Name	Design	Features	Typical appli- cations
1	0874-490-016		Membrane filter	PCV ho- using, PTFE membrane with a lami- nated film, pore size: 1 µm	Average effe- ct of filtration, maximal tem- perature: up to 80oC, respon- se time t10/90: 15 s	Building auto- mation, for use in the rooms with small pol- lution
2	0874-490-015		PTFE filter	Sintered PTFE, pore size 50 µm	High chemical resistance, ma- ximaltemperatu- re: up to 180 °C, response time t10/90:14 s	Drying process in chemical ap- plications
3	0874-490-014		Sintered bronze filter	Sintered bronze, pore size 60 µm	High mechani- cal resistance, used in high pollution and low humidity, response time t10/90: 10 s	Agriculture

6. TECHNICAL DATA

Basic parameters:

 range of relative humidity measurement (RH) 	0100%, without condensation ¹⁾
- basic error of humidity	
conversioni	± 2% of the range for RH = 1090% ± 3% for the remaining range
- hysteresis of the humidity	
measurement	± 1% RH
 basic range of temperature 	
measurement (T)	-2060°C ²⁾
 basic error of temperature 	
conversion	± 0.5% of the range*
* for the versions with analog outputs P a basic error of temperature conversion	18(D)-1, P18(D)-2, P18(D)-4 or P18(D)-5, may increase by 0.2°C
- calculated values	absolute humidity (a) [g/m³] dew-point temperature (Td) [ºC]
 additional errors: 	
- temperature influence	± 25% of the basic error /10°C
RS-485 digital output:	
- transmission protocol	MODBUS
- baud rate	4800, 9600, 19200, 38400,
	57600 bit/s
- mode	RTU: 8N2, 8E1, 8O1, 8N1
- max. response time	300 ms
Analog outputs:	
- current	420 mA
- voltage	010 V
- max. load resistance	
of the current output	100 Ω
- min. load resistance	
of the voltage output	1 kΩ

Rated operating conditions:

- supply	<u>924</u> V a.c./d.c.
- power consumption	< 0.5 VA
- ambient temperature	- 20 <u>23</u> 60°C
- relative air humidity	< 95% ³⁾
- rate of air flow	≥ 0,5 m/s ⁴⁾
- preheating time	15 minutes
- protection grade ensured	
by the housing	IP 65
- fixing	on a wall
- weight	125 g
- dimensions	$(35 imes 58 imes 118) ext{ mm}$

- working position:
 - · in applications non-exposed to a direct contact with water: any
 - in applications exposed to a direct contact with water: with the sensor chamber directed towards the ground

Electromagnetic compatibility:

- noise immunity	acc. to EN 61000-6-2
- noise emission	acc. to EN 61000-6-4

Safety requirements acc. to EN 61010-1

V
000 m

¹⁾ In case of condensation of water vapor on the sensor surface, the measurement error may exceed the basic error till a moment of drying up the sensor structure

- ²⁾ The absolute temperature measurement range is -30...85°C but the measurement class is not guaranteed beyond the basic range
- ³⁾ Admissible condensation of water vapor when using additional sensor shields, see Tab. 9)

⁴⁾ For air flow < 0.5 ms, the temperature and humidity measurement error may increase by 100%.

7. ORDERING CODE

			Table	<u> 10</u>
P18(D) -	Х	XX	Х	Х
Analog outputs - sensor:				
without outputs, sensor on the housing	0			
current 420 mA, sensor on the housing	1			
voltage 010V, sensor on the housing	2			
without outputs, probe on the wire 0,5 m	3			
current 420 mA, probe on the wire 0,5 m	4			
voltage 010V, probe on the wire 0,5 m	5			
Version:				
standard		00		
custom-made*		XX		
Language:				
Polish			Ρ	
English			Е	
other*			Х	
Acceptance tests:				
Without extra quality requirements				0
With quality inspection certificate				1
Acc. to customer's request*				Х

* after agreeing with the manufacturer

Code example:

P18D-100E1 means the P18D transducer, standard version with the sensor on the housing with analog current output, English language, with quality inspection certificate.

P18-09C



PCE Americas Inc. 711 Commerce Way Suite 8 Jupiter FL-33458 USA From outside US: +1 Tel: (561) 320-9162 Fax: (561) 320-9176 info@pce-americas.com

PCE Instruments UK Ltd. Units 12/13 Southpoint Business Park Ensign way Hampshire / Southampton United Kingdom, SO31 4RF From outside UK: +44 Tel: (0) 2380 98703 0 Fax: (0) 2380 98703 9 info@industrial-needs.com www.pce-instruments.com/us www.pce-instruments.com/english

www.industrial-needs.com