

Videoscope PCE-VE 1034N-F



Videoscope PCE-VE 1034N-F / 2-Way head / Image and video recordings/ Large 7" LCD display for detailed viewing / Recording on SD card / Images rotatable 360° (90° steps) / Bright LEDs on the camera head / Camera head diam.: 4.5 mm / 0.18 in

The Videoscope PCE-VE 1034N-F is a versatile inspection instrument. Various videoscope cables with different characteristics can be connected to the videoscope. A special advantage of the videoscope is the large display, which offers the user the best possible overview of the area to be viewed due to its dimensions and resolution. The videoscope allows the recording of images and videos, and the videos are additionally stored with an audio recording. The clear resolution becomes evident when you view the images which can be saved to the videoscope's SD card by a keystroke. When the SD card is read from the computer, the recorded images and videos are clearly displayed. Due to the fact that the recordings are stored on an external mass storage device, it is possible to select which SD card is inserted into the videoscope. The maximum capacity, however, should be 32 GB. An 8 GB memory card allows you to store more than 60,000 images or more than 530 minutes of video material.

Especially in places that are difficult to access, the two-way optics is a great advantage of the videoscope. However, if the control of the camera head is not sufficient and images on the display can not be shown satisfactorily, there is still the possibility to rotate the images on the display of the handset at a 90° angle. In addition to the image rotation, various other functions can also be set on the handset itself. For example, the videoscope allows a digital zoom as well as the setting of the LED brightness of the camera head. The videoscope has a thread at the back which allows the user to position the main unit on a tripod to carry out permanent recordings. The automatic switch-off function can be activated or deactivated in the menu by the videoscope. In addition, when the automatic switch-off is activated, different time intervals between 5 and 30 minutes can be selected. In addition to the tripod, the main unit can also be comfortably held by the padded shoulder straps.

- ▶ 3 m / 9.8 ft borescope cable with 2 way camera-head
- ▶ Camera head diameter: 4.5 mm / 0.18 in
- ▶ Storage of pictures and videos
- ▶ 8 GB memory card incl.
- ▶ LED lighting
- ▶ Robust carrying case incl.

Subject to change

Specifications

Display	7" LCD (800 x 480)
Image resolution	640 x 480 JPEG
Video recording	640 x 480 MPEG (with sound recording)
Drop test	1 m / 3.3 ft
Power supply	Li-Ion rechargeable battery
Interface	USB
Image and video storage	On SD card (maximum 32 GB)
AV output	NTSC / PAL
Audio input	Built-in microphone
Brightness adjustment	10-step adjustable on the main unit
Runtime per battery charge	5 hours
Battery charging time	3 hours
Charging temperature	10 ... 40°C / 50 ... 104°F
Operating temperature	0 ... 60°C / 32 ... 140°F
Storage temperature	0 ... 60°C / 32 ... 140°F
Protection class	IP57
Dimensions	240 x 154 x 47 mm / 9.4 x 6 x 1.9 in
Weight	1.3 kg / 2.9 lb
Cable length	3 m / 9.8 ft
2-way borescope cable	90°
	Lighting improvements
	360° rotation in 90° increments
Functions on the control unit of the cable	Change of lighting for mirror use
	Camera head locking
	Keylock
Lighting	5 white LEDs on camera head
Camera head length	ca. 13 mm / 0.5 in
Camera head material	Stainless steel
Camera head diameter	4.5 mm / 0.18 in
Resolution	VGA (640 x 480)
Depth of field	10 ... 60 mm / 0.4 ... 2.4 in
Operating and storage temperature	-20 ... 60°C / -4 ... 140°F
Protecton class	IP67
Video output	NTSC
Viewing angle	135°
Control unit dimensions	228 x 35 x 53 mm / 9 x 1.4 x 2.1 in
Weight	ca. 400 g / ca. 14 oz.

More information

Manual



More product info



Similar products



Subject to change