

Pressure Meter PCE-P30-ICA Incl. ISO Calibration Certificate



PRODUCT	MEASUREMENT RANGE (PSI)		MEASUREMENT RANGE (Bar)		MEASUREMENT RANGE (Pa)	
	MIN	MAX	MIN	MAX	MIN	MAX
PCE-PDA 01L	-0.029	0.029	-0.002	0.002	-200	200
PCE-PDA 1L	-0.29	0.29	-0.02	0.02	-2000	2000
PCE-PDA 10L	-2.9	2.9	-0.2	0.2	-20000	20000
PCE-PDA 100L	-14.5	29.0	-1	2	-100000	200000
PCE-BDP 10	-2	2	-0.14	0.14	-13790	13790
PCE-P01	-2	2	-0.14	0.14	-13790	13790
PCE-P05	-5	5	-0.34	0.34	-34475	34475
PCE-P15	0	15	0	1.03	0	103425
PCE-P30	0	30	0	2.07	0	206850
PCE-P50	0	50	0	3.45	0	344750
PCE-910	-29	29	-2	2	-200000	200000
PCE-917	-101.5	101.5	-7	7	-700000	700000
PCE-HVAC 4	-14	500	-0.97	34.48	-96530	3447500



PCE-P30 Pressure Meter incl. ISO calibration certificate

Handheld dual-port digital manometer measures gauge pressure and true differential pressure from 0 to 30 psi

PCE-P30 is a pressure meter used to measure gauge pressure and true differential pressure in pneumatic, hydraulic, compressor and pump installations, valves, tanks and heating, ventilation and air conditioning (HVAC) systems. 11 pressure units are selectable for Imperial and Metric measurement, including bar, mmHg, ozin², kgcm², psi, inH₂, kPa, ftH₂O, inHg, cmH₂O and mbar.

Gauge pressure is measured relative to the ambient atmospheric pressure. Thus, changes in the atmospheric pressure due to weather conditions or altitude directly influence the output of a gauge pressure sensor. A gauge pressure higher than the ambient pressure is referred to as positive pressure. If the measured pressure is below the atmospheric pressure, it is called negative or vacuum gauge pressure.

Although most gauge pressure sensors technically are differential pressure sensors — measuring the difference between the media and atmospheric pressure — true differential pressure sensors are used to identify the difference between two separate physical areas. PCE-P30 features two pressure ports and a differential pressure function for measuring true differential pressure.

- ▶ 0 to 30 psi pressure measuring range
 - ▶ 11 pressure units: bar, mmHg, ozin², kgcm², psi, inH₂, kPa, ftH₂O, inHg, cmH₂O, mbar
 - ▶ Maximum / minimum, average, differential pressure and data hold functions
 - ▶ Auto power off (can be disabled)
 - ▶ Large LCD screen with backlight
 - ▶ ABS plastic housing
 - ▶ Connects to PC via RS-232 interface (cable and software not included - see accessories)
- **Incl. ISO calibration certificate**

Specifications

Pressure measuring range: 0 to 30 psi

Pressure units of measure: bar, mmHg, ozin², kgcm², psi, inH₂, kPa, ftH₂O, inHg, cmH₂O, mbar

Resolution: 0.02 psi

Accuracy: ± 0.3% of full scale at 25°C / 77°F

Response time: 0.5 seconds

Power supply: 1 x 9V battery

Approx. Dimensions: 72 x 182 x 30 mm / 2.84 x 7.17 x 1.18 in

Approx. Weight: 220 g / < 1 lb (with battery)

See user manual for complete technical specifications.

More information

Manual



More product info



Similar products



Subject to change