



# User Manual

Digital Pressure Gauge PCE-DPG Series



User manuals in various languages (français, italiano, español, português, nederlands, türk, polski, русский, 中文) can be found by using our product search on: [www.pce-instruments.com](http://www.pce-instruments.com)

Last change: 30 July 2020  
v1.0



## Contents

<b>1</b>	<b>Safety notes</b> .....	<b>1</b>
<b>2</b>	<b>Description</b> .....	<b>2</b>
2.1	Technical specifications .....	2
2.2	Delivery contents.....	3
2.3	Display description .....	3
2.4	Key description.....	3
<b>3</b>	<b>Warranty</b> .....	<b>4</b>
<b>4</b>	<b>Disposal</b> .....	<b>4</b>

## 1 Safety notes

Please read this manual carefully and completely before you use the device for the first time. The device may only be used by qualified personnel and repaired by PCE Instruments personnel. Damage or injuries caused by non-observance of the manual are excluded from our liability and not covered by our warranty.

- The device must only be used as described in this instruction manual. If used otherwise, this can cause dangerous situations for the user and damage to the meter.
- The instrument may only be used if the environmental conditions (temperature, relative humidity, ...) are within the ranges stated in the technical specifications. Do not expose the device to extreme temperatures, direct sunlight, extreme humidity or moisture.
- Do not expose the device to shocks or strong vibrations.
- The case should only be opened by qualified PCE Instruments personnel.
- Never use the instrument when your hands are wet.
- You must not make any technical changes to the device.
- The appliance should only be cleaned with a damp cloth. Use only pH-neutral cleaner, no abrasives or solvents.
- The device must only be used with accessories from PCE Instruments or equivalent.
- Before each use, inspect the case for visible damage. If any damage is visible, do not use the device.
- Do not use the instrument in explosive atmospheres.
- The measurement range as stated in the specifications must not be exceeded under any circumstances.
- Non-observance of the safety notes can cause damage to the device and injuries to the user.

We do not assume liability for printing errors or any other mistakes in this manual.

We expressly point to our general guarantee terms which can be found in our general terms of business.

If you have any questions please contact PCE Instruments. The contact details can be found at the end of this manual.



## 2 Description

The digital pressure gauge is mainly composed of a housing, a pressure sensor and a signal processing circuit and has the advantages of high precision, good corrosion resistance, impact resistance, shock resistance, small temperature drift, and good stability.

Please note the following when using:

1. Clear it before use. Due to the difference in atmospheric pressure and stress after installation, the product may show a little pressure. Please clear it before using it again (make sure the meter is not under pressure when it is cleared).
2. This product has a built-in pressure sensor, which is a precision device. Please do not disassemble it yourself. Do not use a hard object to probe or touch the diaphragm to avoid damaging the sensor.
3. Use a wrench to install. Before installing the product, make sure that the interface threads match the gauge threads and use a hex wrench; do not rotate the case directly.

### 2.1 Technical specifications

Type PCE-DPG	3	6	10	25	100	200
Measurement range	-14.5...43.5 psi, -1...3 bar	0...87 psi, 0...6 bar	0...145 psi, 0...10 bar	0...362.6 psi, 0...25 bar	0...1450 psi, 0...100 bar	0...2900 psi, 0...200 bar
Resolution	0.0145 psi, 0.001 bar		0.145 psi, 0.01 bar			1.45 psi, 0.1 bar
Accuracy	0.25% FSO					
Pressure	Relative					
Overpressure	1.5 times					
Measurable media	Gases, water					
Response time	<50 ms					
Housing material	Metal					
Measurement units	Mpa, bar, Kpa, mH2o, kg / cm <sup>2</sup> , psi, mmH2o, in.WC, mbar					
Protection class	IP56					
Diameter display	2.5"					
Dimensions	Ø80 x 50 mm / 3.1 x 2 in (without sensor)					
Pressure connection	1/40" NPT					
Power supply	3 x 1.5 V AAA battery					
Environmental conditions	-10 ... 60 °C / 14 ... 140 °F, <80 % RH					
Weight	approx. 276 g / <1 lb (without batteries)					

## 2.2 Delivery contents





1 x digital pressure gauge PCE-DPG  
 3 x batteries 1.5 V AAA  
 1 x user manual

## 2.3 Display description



1. Percentage graph
2. Peak indicator
3. MAX indicator
4. MIN indicator
5. Battery status indicator
6. Current pressure indicator
7. Pressure unit

## 2.4 Key description

	On / Off
	Pressing for short time – switching pressure unit Pressing for a long time – zero calibration
	Pressing for a long time – clear peak Pressing for a short time – switch the max. and min. peak
	Pressing for a short time – activate the backlight Pressing for long time – set backlight duration <ol style="list-style-type: none"> <li>1. Press the backlight key for 3 seconds</li> <li>2. With the unit key you shift between the two digits.</li> <li>3. By pressing the backlight key you change the number.</li> <li>4. To save the number and exit the menu, press the peak key.</li> </ol>



### 3 Warranty

You can read our warranty terms in our General Business Terms which you can find here: <https://www.pce-instruments.com/english/terms>.

### 4 Disposal

For the disposal of batteries in the EU, the 2006/66/EC directive of the European Parliament applies. Due to the contained pollutants, batteries must not be disposed of as household waste. They must be given to collection points designed for that purpose.

In order to comply with the EU directive 2012/19/EU we take our devices back. We either re-use them or give them to a recycling company which disposes of the devices in line with law.

For countries outside the EU, batteries and devices should be disposed of in accordance with your local waste regulations.

If you have any questions, please contact PCE Instruments.



## PCE Instruments contact information

### Germany

PCE Deutschland GmbH  
Im Langel 4  
D-59872 Meschede  
Deutschland  
Tel.: +49 (0) 2903 976 99 0  
Fax: +49 (0) 2903 976 99 29  
info@pce-instruments.com  
www.pce-instruments.com/deutsch

### United Kingdom

PCE Instruments UK Ltd  
Unit 11 Southpoint Business Park  
Ensign Way, Southampton  
Hampshire  
United Kingdom, SO31 4RF  
Tel: +44 (0) 2380 98703 0  
Fax: +44 (0) 2380 98703 9  
info@pce-instruments.co.uk  
www.pce-instruments.com/english

### The Netherlands

PCE Brookhuis B.V.  
Institutenweg 15  
7521 PH Enschede  
Nederland  
Telefoon: +31 (0)53 737 01 92  
info@pcebenelux.nl  
www.pce-instruments.com/dutch

### United States of America

PCE Americas Inc.  
711 Commerce Way suite 8  
Jupiter / Palm Beach  
33458 FL  
USA  
Tel: +1 (561) 320-9162  
Fax: +1 (561) 320-9176  
info@pce-americas.com  
www.pce-instruments.com/us

### France

PCE Instruments France EURL  
23, rue de Strasbourg  
67250 Soultz-Sous-Forets  
France  
Téléphone: +33 (0) 972 3537 17  
Numéro de fax: +33 (0) 972 3537 18  
info@pce-france.fr  
www.pce-instruments.com/french

### Italy

PCE Italia s.r.l.  
Via Pesciatina 878 / B-Interno 6  
55010 Loc. Gragnano  
Capannori (Lucca)  
Italia  
Telefono: +39 0583 975 114  
Fax: +39 0583 974 824  
info@pce-italia.it  
www.pce-instruments.com/italiano

### China

PCE (Beijing) Technology Co., Limited  
1519 Room, 6 Building  
Zhong Ang Times Plaza  
No. 9 Mentougou Road, Tou Gou District  
102300 Beijing, China  
Tel: +86 (10) 8893 9660  
info@pce-instruments.cn  
www.pce-instruments.cn

### Spain

PCE Ibérica S.L.  
Calle Mayor, 53  
02500 Tobarra (Albacete)  
España  
Tel. : +34 967 543 548  
Fax: +34 967 543 542  
info@pce-iberica.es  
www.pce-instruments.com/espanol

### Turkey

PCE Teknik Cihazları Ltd.Şti.  
Halkalı Merkez Mah.  
Pehlivan Sok. No.6/C  
34303 Küçükçekmece - İstanbul  
Türkiye  
Tel: 0212 471 11 47  
Faks: 0212 705 53 93  
info@pce- cihazlari.com.tr  
www.pce-instruments.com/turkish

### Hong Kong

PCE Instruments HK Ltd.  
Unit J, 21/F., COS Centre  
56 Tsun Yip Street  
Kwun Tong  
Kowloon, Hong Kong  
Tel: +852-301-84912  
jyi@pce-instruments.com  
www.pce-instruments.cn