

PCE Americas Inc.
711 Commerce Way
Suite 8
Jupiter
FL-33458
USA

From outside US: +1
Tel: (561) 320-9162
Fax: (561) 320-9176
info@pce-americas.com

PCE Instruments UK Ltd.
Units 12/13
Southpoint Business Park
Ensign way
Hampshire / Southampton
United Kingdom, SO31 4RF

From outside UK: +44
Tel: (0) 2380 98703 0
Fax: (0) 2380 98703 9
info@pce-instruments.com

www.pce-instruments.com/english
www.pce-instruments.com

Color Meter for Medical / Pharmaceutical Industry

Differentiation and also classification of pills can be made by color easily. Capsules and pills are produced in various shapes and colors. It is also usual to have loose or pressed powders.

All these different kind of appearance do not only need an accurate color meter - it is very important to have the probe holder or applicator that fits perfect to the product. For powders the instrument type with 45°/0° geometry are used as well as for opaque pill samples. For translucent pills, color meters with all kind of geometry can work proper. You have to find out what works the best in your application. In case of transparent capsules must be measured by instruments which use the transmission principle.

