

Ultrasonic Flow Meter PCE-TDS 100H



Ultrasonic Flow Meter PCE-TDS 100H

Measures liquid flow velocity in pipes and tubes with a diameter of 57 ... 720 mm / \approx 2 ... 28 in

This is a portable handheld clamp-on ultrasonic flow meter used for non-invasive, unobstructed and highly accurate measurements of the flow velocity of liquids in metal, plastic and rubber pipes and tubes with a diameter of 57 ... 720 mm / approx. 2 ... 28 in. Ideal for use in oil and gas, water and wastewater, chemical, food and beverage, pharmaceutical, metals and mining, pulp and paper, power and heating, ventilation, air conditioning and refrigeration (HVACR) industries, this ultrasonic flow meter features user-friendly velcro-strap clamps that allow for quick and easy repositioning of the electroacoustic transducers.

Measurable liquids include: acetate, acetone, alcohol, ammonia, aniline, benzene, butyrate, chloroform, ethanol, ethyl alcohol, ethyl ether, ethylene glycol, freon R 12, petrol, glycerin, glycol, isobutanol, isobutane, isopentane, kerosene, linseed oil, methanol, methyl alcohol, engine oil, diesel oil, olive oil, peanut oil, paraffin oil, pentane, petroleum, 1-propanol, coolant, lubricating oil, silicone oil, transformer oil, trichlorethylene, 1, 1, 1 - trichloroethane, turpentine, distilled water and sea water.

The transit-time principle requires pipes to be full and have no bubbles and no particles.

Note: To transfer data to a computer, SOFT-PCE-TDS software is required. This software is sold separately - see accessories for details.

Each PCE-TDS series meter is assembled by PCE Instruments in Germany and is factory-calibrated (without any documentation). The reference display of the in-house test stand used by PCE for calibration has a valid DAkkS calibration certificate. This ensures traceability to the Physikalisch-Technische Bundesanstalt (PTB) German national standard. Please note that the meter's measured values depend on the pipe geometry, material and coating; the medium type, temperature and speed; and the sensor type and measuring method.

- ▶ ideal for retrofitting
- ▶ installation without process interruption
- ▶ easy assembly
- ▶ accurate and reliable
- ▶ no pressure loss
- ▶ maintenance-free, no moving parts
- ▶ wear-free
- ▶ portable devices for control measurements

Subject to change

Specifications

Handheld measuring range	-32 ... +32 m/s
Resolution	0.0001 m/s, 0.00033 ft/s
Accuracy for DN ≥ 50 mm:	±1.5 % of measured value ±3.5 % of measured value
for DN < 50 mm:	
Reproducibility	±1.0 % of measured value
Media	All liquids with an impurity <5% and a flow >0.03 m ³ /h
Flow units	Cubic meter [m ³] Liter [l] Gallon (USA) [gal] Imperial gallon (UK) [igl] Million USA gallon [mgl] Cubic foot [cf] Barrel (USA) [bal] Imperial barrel (UK) [ib] Oil barrel [ob]
Time settings	per day [/d] per hour [/h] per minute [/m] and per second [/s]
Data logger	1800 measurements
Interface	USB (for online measurement and reading of the internal memory)
Protection	IP 52
Power supply	3 x AA NiMH rechargeable battery / 2100 mAh (at full charge 12h running time) 100 ... 240 V AC 50/60 Hz
Dimensions	214 x 104 x 40 mm / 8.4 x 4.1 x 1.5"
Weight	450 g / 15 oz
Sensor (only PCE-TDS 100 H)	nominal width DN 50 ... 700, 57 ... 720 mm / approx.2 ... 28"
Temperature of liquid	-30 ... 160 °C / -22 ... 320 °F
Dimensions	50 x 45 x 45 mm / 1.9 x 1.7 x 1.7"
Weight	260 g / 9oz

More information

Manual



Manual P1



Video Quick Start



Video



More product info



Similar products



Subject to change