



Paper Scale Round Sample Cutter PCE-FSC 25



Paper scale round sample cutter for 25 cm² samples, robust and compact, four blades, up to 5 mm

The paper scale round sample cutter impresses with its compact dimensions and the robust steel housing. With the four internal blades of the round sample cutter, you can cut out a 25 cm² sample (fleece, paper, leather, textile, cork, ...) within seconds, a quarter turn is sufficient, and you can measure its weight per unit area.

- ▶ Robust and compact
- ▶ Four internal stainless steel blades
- ▶ Up to 0-5 mm / 0-0.19" material thickness
- ▶ 25 cm² / 3.87 in² sample size
- ▶ With mechanical lock
- ▶ Suitable for many materials

Subject to change

Specifications

Sample thickness	max. 0-5 mm / 0-0.19"
Sample cut-out	25 cm² / 3.87 in²
Housing	cast steel
Cutting blades	stainless steel
Dimensions	135 mm / 5.31", Ø 100 mm / 3.93"
Weight	ca. 500 g / 17.6 oz

More information

More product info



Similar products



Subject to change