

Hay Hygrometer PCE-HMM 50



Hay hygrometer to determine moisture and temperature of hay and straw / Robust design / Four different lengths of measuring lance of 25 cm, 50 cm, 100 cm or 270 cm / Continuous display of measuring value

The hay moisture meter PCE-HMM is a professional device designed to determine moisture and temperature of pressed hay and straw. The hay moisture meter features a sensor made of stainless steel, which can be purchased in four different lengths, while the wooden handle has an ergonomic design. The hay moisture meter PCE-HMM proves to be extremely robust, designed to withstand applications for many years. The measuring range of the hay moisture meter covers 9 ... 50% and a temperature range of -10 ... 100°C / 14 ... 212°F. The LCD display of the hay moisture meter shows continuously the current moisture, so the hay moisture meter can be applied at varying locations and on different bales without the need of performing any manual operation by pressing any keys to start the measurement. Thus the hay moisture meter facilitates assuring the quality of fodder even during harvesting in order to prevent any damage by fungal infestation.

- ▶ Controlling moisture of harvest during trading
- ▶ Safety precaution during storage of hay and straw
- ▶ Assures fodder quality and prevents damages due to fungal infestation
- ▶ Temperature control
- ▶ Robust measuring device for daily operation
- ▶ Designed for application in hay and straw trade

Specifications

Measuring range moisture	9 ... 50%
Measuring range temperature	-10 ... 100°C / 14 ... 212°F
Resolution of display	0.1%
Accuracy	0.8%
Display	LCD with 15 mm cipher height
Keypad	Membrane keyboard
Handle	Stable wooden handle with ergonomic design
Enclosure	Resistant to splashes and dust
Measuring lance	Lance made of stainless steel with 25 cm, 50 cm, 100 cm or 270 cm length
Functions	Hold function, counting function, average value calculation
Display light	Automatic
Switch-off	Automatic
Calibration	Automatic
Power Supply	9V block battery
Dimensions	772 x 70 x 48 mm / 30.3 x 2.7 x 1.8 in (edition with 50 cm lance)
Package size	800 x 78 x 54 mm / 31.4 x 3 x 2.1 in (edition with 50 cm lance)
Weight incl. battery	650 g / 1.4 lbs (edition with 50 cm lance)

More information

Video



More product info



Similar products



Subject to change