

Wind Speed Alarm Controller PCE-WSAC 50W 230-ICA incl ISO calibration cert.







PCE-WSAC 50W 230 Wind Speed Alarm Controller incl ISO calibration certificate

Radio anemometer warning system / Wind monitoring on construction cranes / 4 ... 20-mA analog output / Power supply 110 ... 230V AC

Wind Speed Alarm Controller PCE-WSAC 50W 230 is primarily used to measure and monitor the wind load on cranes or wind turbines. Furthermore, the wind situation can be measured and analyzed before commissioning a wind turbine. The Wind Speed Alarm Controller PCE-WSAC 50W 230 is equipped with alarm relay for a pre-alarm or main alarm.

Due to the high measuring range of up to 50 m/s of the wind speed alarm controller, stormy gusts can also be monitored. The radio range of the wind speed alarm controller is in the open field up to 750 m/2500 ft in the free frequency band of 2.4 GHz. When installing the display of the wind speed alarm controller PCE-WSAC 50W 230 in buildings, a range of up to 60 m/200 ft can be achieved for the wind sensor. Due to the integrated 4 ... 20-mA analogue output of the wind alarm display, the measured data can also be transferred to other controllers for evaluation.

- ► Robust plastic housing
- Units: km / h, mph, m / s
- 4 ... 20-mA analog output
- ▶ 128 x 64 pixel LC display
- Alarm relay
- ▶ Measuring range up to 180 km / h
- Durable stainless steel ball bearings
- ► Ambient temperature -20 ... 70°C / -4 ... 158°F
- ▶ Radio transmission
- ▶ Incl. ISO calibration certificate

Specifications

Display of the Wind Speed Alarm Controller PCE-WSAC 50W 230

Input Pulse, analog (4 ... 20-mA) or radio

Radio IEEE 802.15.4 ISM 2.4 GHz

Units km / h, mph, m / s

Power supply for sensors +15V DC

Analog output 4 ... 20-mA

Maximum input impedance 500Ω Resolution of the analog output 10 bitsAccuracy of the analog output $\pm 1.5\%$

Alarm relay Max. 250V AC, 8 A

Display Backlit 128 x 64 pixel LC display

Casing Robust plastic housing

Protection class IP65

Dimensions 145 x 95 x 125 mm / 5.7 x 3.7 x 4.9 in

Weight 650 g / 1.4 lbs

Sensor of the Wind Speed Alarm Controller PCE-WSAC 50W 230

Measuring range 4 ... 180 km / h

Minimum start speed 8 km / h

Accuracy \pm 1 km / h in the range 4 ... 15 km / h

± 3% in the range 16 ... 180 km / h

Power supply Battery mono cell D 1.5V DC

approx. 0.3 W with 1.5V DC power

supply

Housing material PA + FG

Power consumption

Ball-bearing Stainless steel X65Cr13
Holder Stainless steel AISI 304

Weight (with standard bracket) about 680 g / 1.5 lbs

Geicht with self-leveling bracket about 900 g / 2 lbs

Dimensions 320 x 110 x 100 mm / 12.6 x 4.3 x 3.9 in

Storage temperature $-35 \dots 70^{\circ}\text{C} / -31 \dots 158^{\circ}\text{F}$ Ambient temperature $-20 \dots 70^{\circ}\text{C} / -4 \dots 158^{\circ}\text{F}$

Protection IP65

More information

Manual

More product info



Similar products

