

Material Thickness Meter PCE-TG 150 HT-ICA incl. ISO Calibration Certificate



**Material Thickness Meter with data memory / Adjustable speed of sound /
Calibration reference mounted on the housing / Material thickness measurement up to 300 mm /
Limit alarm / Optional ISO calibration certificate**

The material thickness meter can measure material thicknesses up to 300 mm / 11.81". So that the material thickness of a wide variety of homogeneous materials can be measured, it is possible to store the corresponding speed of sound in the material thickness meter. For materials such as steel, aluminum, zinc, silver and gold, the appropriate sound speeds are already stored in the device library. This means that the material thickness meter can be used universally.

With the limit value function in the material thickness meter, individual maximum and minimum values can be stored. If the measured value of the test piece is outside the limits, the material thickness meter signals this visually. If necessary, the signaling can also be done acoustically by the material thickness meter in addition to the visual display. This is why the material thickness meter is used, for example, in quality assurance and in incoming goods inspections.

The material thickness meter has a data memory on which the measured values can be recorded. After a measurement sequence, the stored measurement values can be analyzed directly on the material thickness meter. The stored data are graphically displayed by the material thickness meter. In addition, each individual measuring point can be approached and read in the graphics of the material thickness meter. For a simplified analysis of the measured values, the average, the largest and smallest measured value is displayed on the material thickness meter.

- ▶ Measured value memory
- ▶ Calibration reference on the housing
- ▶ Automatic shutdown
- ▶ Material thickness measurement up to 300 mm / 11.81"
- ▶ Battery status indicator

Specifications

Measuring range	1.20 ... 300.0 mm / 0.04 ... 11.81"
Resolution	0.01 mm at ≤99.99 mm 0.1 mm at ≥100.0 mm
Accuracy	±0.5 % of measured value + 0.05 mm
Storage space	1500 measured values
Standard sensor	PCE-TG HT
Temperature range sensor	-10 ... 350 °C / 14 ... 662 °F
Probe frequency	5 MHz
Diameter	Ø12mm

Further specifications

Adjustable speed of sound	1000 ... 9999 m/s
Smallest pipe diameter	Ø20 x 3 mm (steel)
Material library	15 memory locations
Calibration reference	4 mm
Display	2.4 inch TFT LCD color display with brightness adjustment
Power supply	3 x 1.5 V AA batteries
Automatic switch-off	switched off, 2, 5, 10, 30 minutes
Ambient conditions	0 ... 40 °C / 32 ... 104 °F, <90 % RH, non-condensing
Dimensions	163 x 82 x 38 mm / 6.4 x 3.2 x 1.5"
Weight	320 g / 11.2 oz

More information

Manual



More product info



Similar products



Subject to change