

pH Meter PCE-PH 30







pH meter PCE-PH 30

pH, conductivity, redox tester with interchangeable sensors / Easy-to-read LC display / Pen pH meter / Automatic temperature compensation

The pH tester PCE-PH 30 is the optimal tool for checking the most important water parameters. The portable pH tester is used to control pH and conductivity. It also serves for simultaneous temperature measurement. Furthermore, the pH tester can be used to measure the redox potential.

A three-point calibration and automatic temperature compensation up to 90°C / 194°F guarantee high accuracy even with fluctuating measuring temperatures. The pH tester has a readable display. The test device is supplied with pH and temperature probe, calibration and storage fluid. The redox probe is available separately as an accessory.

- ▶ 6 in 1 pH tester
- ▶ IP57 housing
- ▶ Automatic temperature compensation
- Battery operation
- ▶ 3 point pH calibration
- ► Exchangeable electrodes
- ▶ Max-Min Hold function
- ► Automatic electrode detection

Subject to change

Specifications

Measuring function рΗ

Measuring range -2 ... 16 pH Resolution 0.01 pH

Accuracy \pm 0,01pH + 1Dgt ATC 0 ... 90°C / 32 ... 194°F

Calibration pH 4, 7, 10

Measuring function Redox ± 1000 mV Measuring range Resolution 1 mV

Accuracy \pm 2 mV + 1 Dgt

Measuring function Conductivity

Measuring range $0 \dots 2000 \ \mu S, \ 2 \dots 20 \ mS$

Resolution 1 μS, 0.01 mS

Accuracy ± 2% of measuring range ATC 0 ... 50°C / 32 ... 122°F Calibration $0 \mu S$, 1413 μS , 12.88 mS

Measuring function **TDS**

Measuring range 0 ... 1300 ppm, 1.3 ... 13 ppt

Resolution 1 ppm, 0.01 ppt

Accuracy ± 2% of measuring range ATC 0 ... 50°C / 32 ... 122°F

Measuring function Salinity

Measuring range 0 ... 1000 ppm, 1 ... 12 ppt

Resolution 1 ppm, 0.01 ppt

Accuracy ± 2% of measuring range 0 ... 50°C / 32 ... 122°F ATC

Measuring function **Temperature**

Measuring range 0 ... 90°C / 32 ... 194°F

Resolution 0.1°C / 0.18°F

Accuracy ± 0.2 °C / 0.36°F + 1 Dgt

LCD display Display

Power supply 4 x 1.5V AAA battery

Dimensions 195 x 40 x 36 mm / 7.7 x 1.6 x 1.4 in

Weight About 135 g / < 1 lb

More information

Manual



More product info



Similar products

